

Firmware Tde Macno

User's manual
OPDE Energy application n°3



MW01501E00 V_1.3



TABLE OF CONTENTS

1	OVERVIEW	3
2	CONNECTIONS	3
2.1	I/O CONNECTIONS FOR PHOTOVOLTAIC APPLICATION	3
2.2	I/O CONNECTIONS FOR APPLICATION WITH ROTATING MACHINE CONNECTED TO AN AC/DC INVERTER	4
2.3	I/O CONNECTIONS FOR ENERGY STORAGE SYSTEM (ESS)	4
3	APPLICATION CONFIGURATION	5
3.1	APPLICATION PARAMETERS	5
3.2	APPLICATION CONNECTIONS	6
3.3	APPLICATION INTERNAL VALUES	7
3.4	APPLICATION EXTRA PARAMETERS	8
3.5	APPLICATION OSCILLOSCOPE VALUES AND ANALOG OUTPUTS	8
3.6	APPLICATION LOGIC INPUTS	9
3.7	APPLICATION LOGIC OUTPUTS	10
3.8	STATUS WORD	11
3.8.1	Core status word	11
3.8.2	Application status word	11
3.9	APPLICATION ALARM WORD	11
4	OPERATION	12
4.1	CAPABILITY	12
4.1.1	Capability for Wind/Hydro	12
4.1.2	Capability for ESS	13
4.2	APPLICATION SELECTION	14
4.3	OPERATING SEQUENCES (ONLY WITH E26=1)	15
4.3.1	Off Status [0]	16
4.3.2	Stand-By Status [1]	16
4.3.3	Connecting Mode Status [2]	16
4.3.4	Init MPPT & PMIN Control Status [5]	16
4.3.5	Grid Mode Status [3]	17
4.3.6	Minimum Power Wait Mode Status [7]	17
4.3.7	PV Sweep Status [8]	17
4.3.8	Vmppt ramp [9]	17
4.3.9	Maintenance Status [4]	17
4.4	LOCKING OF THE CONVERTER (ONLY WITH E26=1)	17
4.5	MPPT FUNCTION (ONLY WITH E26=1)	18
4.5.1	Manual MPPT	18
4.5.2	Automatic MPPT	18
4.5.3	Function parameters	18
4.6	GRID FREQUENCY CONTROL FUNCTION (ONLY WITH E26=1)	18
4.6.1	Function parameters	19
4.7	MAINTENANCE FUNCTION (ONLY WITH E26=1)	19
4.7.1	Function parameters	19
4.8	AMBIENT TEMPERATURE CONTROL FUNCTION (ONLY WITH E26=1)	19
4.8.1	Function parameters	19
4.9	AC POWER MEASUREMENT – CALCULATION OF PRODUCED ENERGY	19
4.9.1	Function parameters	20
4.10	MANAGING THE INTERFACE PROTECTION	20
4.11	CURRENT REFERENCE	20
4.11.1	Function Parameters	20
4.12	FIELD BUS REFERENCE AND LIMIT	20
4.12.1	Function parameters	20
4.13	PWM SYNCHRONIZATION	21
4.13.1	Function parameters	21
4.14	ACTIVE POWER CONTROL P(F)	22
4.14.1	P(F) for PV and Wind/Hydro	22
4.14.2	P(F) for ESS	23
4.14.3	Function parameters	24
4.15	ACTIVE POWER CONTROL P(V)	24
4.15.1	P(V) for PV and Wind/Hydro	24
4.15.2	P(V) for ESS	25

4.15.3	Function parameters.....	25
4.16	GRID CONNECTION REQUIREMENTS.....	25
4.16.1	CEI 0-21 operating mode (E93=1).....	25
4.16.2	CGC/GF004 operating mode (E93=2).....	26
4.16.3	Function parameters.....	27
4.17	REACTIVE POWER CONTROL Q(V).....	27
4.17.1	Q(V) for PV and Wind/Hydro.....	27
4.17.2	Q(V) for ESS.....	28
4.17.3	Function parameters.....	29
4.18	REACTIVE POWER CONTROL COSPHI=F(P).....	29
4.18.1	Function parameters.....	30
4.19	REACTIVE POWER Q RAMP (E25=0).....	30
4.19.1	Function parameters.....	30
4.20	THERMAL PROTECTION.....	30
4.20.1	Function parameters.....	31
4.21	EXTERNAL COMMANDS.....	31
4.21.1	Function parameters.....	31
4.22	ANTI ISLANDING FUNCTION.....	31
4.22.1	Function parameters.....	32
4.23	VOLTAGE DROP COMPENSATION.....	32
4.23.1	Function parameters.....	32
4.24	LVFRT.....	32
4.24.1	LVFRT hardware connection.....	34
4.24.2	Function parameters.....	34
4.25	ENERGY AND POWER.....	35
4.25.1	Function parameters.....	35
4.26	DC INPUT.....	35
4.26.1	Function parameters.....	35
4.27	PV SWEEP (ONLY WITH E26=1).....	35
4.27.1	Function parameters.....	36
4.28	Id COMPENSATION.....	37
4.28.1	Function parameters.....	37
4.29	GRID ISLAND CONTROL (ONLY WITH E25=1).....	37
4.29.1	Function parameters.....	37
4.30	STORAGE (ONLY WITH E25=1).....	38
4.30.1	Function parameters.....	38
4.31	TRANSFORMERLESS.....	38
4.31.1	Rgrid tuning.....	39
4.31.2	Function parameters.....	40
4.32	CYCLIC.....	41
4.32.1	Function parameters.....	41
4.33	AUTOMATIC ALARM RESET (ONLY WITH E26=1).....	41
4.34	MAPPED OBJECT - FIELD BUS OBJECT DICTIONARY.....	42
5	ITALIAN GRID CODE OVERVIEW.....	43
5.1	ACTIVE POWER LIMITATION MANAGEMENT.....	44
6	ALARMS.....	45
7	DISPLAY - REMOTE KEYPAD.....	48
7.1	DISPLAY PHYSICAL DISPOSITION.....	48
7.2	REMOTE KEYPAD PHYSICAL DISPOSITION.....	48
7.3	DISPLAY – REMOTE KEYPAD USE.....	49
8	REVISION HISTORY.....	50

APPLICATION VERSION 3.04

1 OVERVIEW

The OPDE_Energy application integrates within the AFE converter all of the functions required to manage the “OPDE AFE Energy” converter used as:

- converter for photovoltaic applications (for example in the TDE Macno photovoltaic inverter “OPDE Solar”);
- converter for hydroelectric and wind applications;
- converter for energy storage system (ESS).

In addition to the standard AFE converter parameters, which are described in the relevant **AFE user manual**, OPDE_Energy application includes a set of additional parameters and quantities, which may be grouped as follows:

- application parameters;
- application internal values;
- application oscilloscope values;
- application logic inputs;
- application logic outputs;
- application alarms.

The correct use of these parameters and quantities is described in the following sections.

2 CONNECTIONS

The OPDE_Energy application sw is used as control sw for the OPDE AFE Energy converter in different application like photovoltaic, hydroelectric, wind and storage. Therefore, two types of installation will be taken into consideration:

- photovoltaic application;
- application with rotating machine connected to an AC/DC inverter.
- storage application.

For a detailed description of the connections, refer to the OPDE AFE Energy Installation Manual.

The I/O connections differ depending on the type of application, as described below.

2.1 I/O CONNECTIONS FOR PHOTOVOLTAIC APPLICATION

In a photovoltaic application the converter “OPDE AFE Energy” has a PV field connected to the DC-Bus. In this case it's necessary to enable the MPPT function that regulates the DC-Bus voltage to generate the maximum power from the PV plant.

Furthermore, other external components must be connected to the AFE I/O to work properly. For a detailed description refer to the OPDE AFE Energy installation manual. The default I/O configuration is listed below.

Default I/O – PV application		
Input	Default	Connection
L.I.1	I27 – Surge Protection Device OK	C01 = 27
L.I.2	I00 – Run command	C02 = 0
L.I.3	I31 – Interface protection OK	C03 = 31
L.I.4	I30 – PV switch close AND PV insulation OK	C04 = 30
L.I.5	I29 – Fan OK	C05 = 29
L.I.6	I28 – Grid contactor close AND line fuse OK	C06 = 28
L.I.7	Not Enabled (free input)	C07 = -1
L.I.8	Not Enabled (free input)	C08 = -1
Output	Default	Connection
L.O.1	O23 – Enable AFE fans	C10 = 23
L.O.2	O33 – On-grid contactor command	C11 = 33
L.O.3	O36 – Active power limitation	C12 = 36
L.O.4	O33 – On-grid contactor command	C13 = 33
Analog Output	Default	Connection
A.O.1	osc11 – Current module	C15 = 11
A.O.2	osc86 – P active limit	C16 = 86

Tab. 1 – Default I/O configuration for PV application

2.2 I/O CONNECTIONS FOR APPLICATION WITH ROTATING MACHINE CONNECTED TO AN AC/DC INVERTER

In an application with a rotating machine the converter “OPDE AFE Energy” has an AC/DC inverter connected to the DC-Bus. In this case it's necessary to work only with the DC-Bus voltage regulation (default working mode). The default I/O configuration is listed below.

Default I/O – Rotating machine		
Input	Default	Connection
L.I.1	I08 – Reset alarms	C01 = 8
L.I.2	I02 – Extern enable	C02 = 2
L.I.3	I31 – Interface protection OK	C03 = 31
L.I.4	I00 – Run command	C04 = 0
L.I.5	Not Enabled (free input)	C05 = -1
L.I.6	Not Enabled (free input)	C06 = -1
L.I.7	Not Enabled (free input)	C07 = -1
L.I.8	I26 – PWM Synchronization input	C08 = 26
Output	Default	Connection
L.O.1	O23 – Enable AFE fans	C10 = 23
L.O.2	O33 – On-grid contactor command	C11 = 33
L.O.3	O36 – Active power limitation	C12 = 36
L.O.4	O33 – On-grid contactor command	C13 = 33
Analog Output	Default	Connection
A.O.1	osc11 – Current module	C15 = 11
A.O.2	osc86 – P active limit	C16 = 86

Tab. 2 – Default I/O configuration for rotating machine

2.3 I/O CONNECTIONS FOR ENERGY STORAGE SYSTEM (ESS)

In an energy storage system (ESS) the converter “OPDE AFE Energy” has a battery connected to the DC-Bus. In this case the AFE must be set to work in CSI mode (Current Source Inverter), in order to regulate the ac current without regulate the DC-Bus voltage (E25=1).

The default I/O configuration is listed below.

Default I/O – Rotating machine		
Input	Default	Connection
L.I.1	I08 – Reset alarms	C01 = 8
L.I.2	I02 – Extern enable	C02 = 2
L.I.3	I31 – Interface protection OK	C03 = 31
L.I.4	I00 – Run command	C04 = 0
L.I.5	I25 – Enable stopping ramp	C05 = 25
L.I.6	Not Enabled (free input)	C06 = -1
L.I.7	Not Enabled (free input)	C07 = -1
L.I.8	Not Enabled (free input)	C08 = -1
Output	Default	Connection
L.O.1	O23 – Enable AFE fans	C10 = 23
L.O.2	O33 – On-grid contactor command	C11 = 33
L.O.3	O36 – Active power limitation	C12 = 36
L.O.4	O33 – On-grid contactor command	C13 = 33
Analog Output	Default	Connection
A.O.1	osc11 – Current module	C15 = 11
A.O.2	osc86 – P active limit	C16 = 86

Tab. 3 - Default I/O configuration for ESS

3 APPLICATION CONFIGURATION

3.1 APPLICATION PARAMETERS

Name	Description	Min	Max	Def	u.m.	Scale
CTRL_PF_F_LOCK_IN_OF	E02 - Lock-in frequency of P=f(F) curve in Over Frequency	45.00	55.00	50.30	Hz	100
CTRL_PF_SLOPE_OF	E03 - Percentage Slope of P=f(F) curve in Over Frequency	2.0	5.0	2.4	% GRID_FREQ_NOM / P_INST	10
V_GRID_MAX	E04 - Maximum grid voltage for enabling grid connection	101	120	110	% V_GRID_NOM	1
V_GRID_MIN	E05 - Minimum grid voltage for enabling grid connection	80	99	85	% V_GRID_NOM	1
F_GRID_MAX	E06 - Maximum grid frequency for enabling grid connection	50.05	55.00	50.10	% F_GRID_NOM	100
F_GRID_MIN	E07 - Minimum grid frequency for enabling grid connection	45.00	49.95	49.90	% F_GRID_NOM	100
GRID_WAIT_TIME_1	E08 - Wait time for enabling grid connection	1	900	30	s	1
GRID_WAIT_TIME_2	E09 - Wait time for enabling grid connection after SPI trigger or over frequency	1	900	300	s	1
ACT_PWR_RAMP_TIME	E10 - Active power ramp time	1	900	300	s	1
F_GRID_MAX_RUN	E11 - Maximum grid frequency for running	50.05	54.00	52.00	Hz	100
F_GRID_MIN_RUN	E12 - Minimum grid frequency for running	46.00	49.95	47.00	Hz	100
V_F_GRID_FILTER	E13 - Vgrid and Fgrid filter time constant	0	999	100	ms	1
K_TRANSF	E14 - Transformer turns ratio	67.50	0.01	100.00		100
PRC_DELTA_VLT	E15 - Voltage drop due to transformer inductance	0.01	100.00	2.00	% V_GRID_NOM	100
PRC_DELTA_VRT	E16 - Voltage drop due to transformer resistor	0.01	100.00	0.50	% V_GRID_NOM	100
GRID_UNB_MAX	E17 - Maximum grid voltage unbalance for enabling run	0.0	100.0	10.0	% V_GRID_NOM	10
I_ACT_NOM	E18 - Active Current at nominal active power	0.0	100.0	90.0	% I_CONV_NOM	10
EXT_COSPHI_REF	E19 - External cosphi reference	-1.000	1.000	1.000		1000
THR_ERR_FRQ_ALL	E20 - Error Frequency Threshold for alarm	0.0	10.0	10.0	% GRID_FREQ_NOM	10
KAI	E21 - AI_Proportional gain for error frequency filtered	-100.0	100.0	10.0		10
FT_LOWPASS	E22 - AI_Cut Frequency Low Pass Filter	1.00	30.00	10.00	Hz	100
FT_HIGHPASS	E23 - AI_Cut Frequency High Pass Filter	0.01	10.00	0.50	Hz	100
N_SAMPLE	E24 - Number of sample for PV Sweep	10	50	10		1
I_PV_MAX	E30 - Maximum PV input current	0.0	2000.0	0.0	A	10
V_GRID_MAX_UNB	E31 - Maximum grid voltage with unbalanced grid for enabling run	0.0	200.0	115.0	% V_GRID_NOM	10
V_GRID_MIN_UNB	E32 - Minimum grid voltage with unbalanced grid for enabling run	0.0	200.0	80.0	% V_GRID_NOM	10
PV_SWEEP_TIME_STEP	E33 - PV sweep time step	1	999	200	ms	1
PV_SWEEP_REP_PERIOD	E34 - PV sweep repetition period	1	180	60	min	1
DELTA_V	E35 - Voltage step MPPT Algorithm	0	20	3	V	1
TIME_STEP	E36 - Time step MPPT Algorithm	0	19999	5000	Tpwm	1
Tau_Ipv_filter	E37 - Time constant Ipv filter	10	0	999	ms	1
Kmult_IPV	E38 - Kmult_Ipv	0	200	100	%	1
K_MANUAL_MPPT	E39 - MPP in % respect Voc measured	70	100	80	%Voc	1
EXT_ACT_PWR_LIM	E40 - External active power limit	0	200	100	% P_ACT_NOM	1
P_START_MIN	E41 - Minimum power for starting sequence	0	100	2	% Ppv_NORM_COEFF	1
DELTA_V_PMIN	E42 - Delta V for minimum power measure	0	100	70	V	1
V_PV_START	E43 - PV voltage for starting sequence	380	780	460	V	1
T1_PMIN	E44 - Repetition time T1 of minimum power measurement	0.1	10.0	1.0	min	10
T2_PMIN	E45 - Repetition time T1 of minimum power measurement T2>T1	0.1	30.0	10.0	min	10
Ton_1	E46 - Waiting time Ton_1	0.1	10.0	0.1	min	10
TEMP_ON_AFE_FAN	E47 - Switch on temperature for AFE fans	30	80	60	°C	1
TEMP_AMB_OFF	E48 - AFE switch off ambient temperature	30	50	41	°C	1
Kmult_Pac	E49 - Pac measured multiplication coefficient				%	1
PERC_GRID_F_CNTRL	E50 - Percentage tolerance for grid frequency control	0.6	10	1	%	10
V_MPPT_MIN	E51 - Minimum MPPT voltage reachable	360	460	360	V	1

V_MPPT_MAX	E52 - Maximum MPPT voltage reachable	680	780	780	V	1
P_GRID_REF	E53 - Active power reference	-200.0	200.0	0.0	% S_NOM	10
Q_GRID_REG	E54 - Reactive power reference	-200.0	200.0	0.0	% S_NOM	10
VB_MAX	E55 - V Bus Max Limit in CSI	0.0	1200.0	0.0	V	10
VB_MIN	E56 - V Bus Min Limit in CSI	0.0	1200.0	0.0	V	10
KP_VB_LIM	E57 - Kp V Bus limit in CSI	0.0	300.0	1.0		10
TI_VB_LIM	E58 - Ti V Bus Limit in CSI	0.0	3000.0	60.0	ms	10
TF_VB_LIM	E59 - Tf V Bus Limit in CSI	0.0	3000.0	0.0	ms	10
CTRL_CP_PWR_A	E60 - Power of point A cosfi=f(P) curve	0	100	20	% P_ACT_NOM	1
CTRL_CP_PWR_B	E61 - Power of point B cosfi=f(P) curve	0	100	50	% P_ACT_NOM	1
CTRL_CP_FV_COSPHI	E62 - Cosphi of point C cosfi=f(P) curve and cosphi of Q=f(V) curve	0.00	1.00	0.90		100
CTRL_CP_V_LOCK_IN	E63 - Lock-in voltage of cosfi=f(P) curve	100	100	105	% V_GRID_NOM	1
CTRL_CP_V_LOCK_OUT	E64 - Lock-out voltage of cosfi=f(P) curve	90	90	100	% V_GRID_NOM	1
COSPHI_NOM	E65 - Nominal Cosphi for definition of D82-S_NOM	0.00	0.00	0.90		100
CTRL_FV_V1S	E66 - V1S voltage of Q=f(V) curve	80	120	108	% V_GRID_NOM	1
CTRL_FV_V2S	E67 - V2S voltage of Q=f(V) curve	80	120	110	% V_GRID_NOM	1
CTRL_FV_V1I	E68 - V1I voltage of Q=f(V) curve	80	120	92	% V_GRID_NOM	1
CTRL_FV_V2I	E69 - V2I voltage of Q=f(V) curve	80	120	90	% V_GRID_NOM	1
CTRL_FV_PWR_LOCK_IN_RE G	E70 - Lock-in power of Q=f(V) curve during regeneration	0	100	20	% P_ACT_NOM	
CTRL_FV_PWR_LOCK_OUT	E71 - Lock-out power of Q=f(V) curve	0	50	100	% P_ACT_NOM	1
CTRL_PV_V1S	E74 - V1S voltage of P(V) curve	108	135	108	% V_GRID_NOM	1
CTRL_PV_V2S	E75 - V2S voltage of P(V) curve	110	135	110	% V_GRID_NOM	1
CTRL_PV_P_LIM	E76 - Active power limit for P(V) curve	0	200	20	% P_ACT_NOM	1
CTRL_FV_PWR_LOCK_IN_AB S	E77 - Lock-in power of Q=f(V) curve during absorption	-100	0	-20	% P_ACT_NOM	1
CTRL_QV_K	E78 - K factor of Q=f(V) curve	-1.00	1.00	0.00	% S_NOM	100
CTRL_QV_DELAY_ON	E79 - Activation delay time of Q=f(V) curve	0	30	3	s	1
PWM_SYNCH_PHASE	E88 - PWM synchronization angle	-175.0	175.0	0	Degrees	10
CTRL_PF_DELAY_ON	E99 - Activation delay timed of P=f(F) curve	0.00	10.00	0.00	s	100

3.2 APPLICATION CONNECTIONS

Name	Description	Min	Max	Def	u.m.	Scale
EN_CURR_REF	E25 - Enable application current reference	0	1	1		1
APPL_SEL	E26 - Application selection	Range		0		1
		0	AFE_STD			
		1	Solar			
EN_FLDBUS_REF	E27 - Enable FIELD-BUS reference values	0	1	0		1
EN_MPPT	E80 - Enable MPPT Algorithm	0	1	1		1
EN_MANUAL_MPPT	E81 - Enable Manual MPPT Algorithm	0	1	0		1
EN_MANUT	E82 - Enable maintenance mode	0	1	0		1
ENERGY_RESET	E83 - Reset produced energy counter	0	1	0		1
EN_VAR_STEP	E84 - Enable variable step MPPT algorithm (unmanaged)	0	1	0		1
EN_TEMP_OFF	E85 - Enable temperature controlled switch off	0	1	0		1
EN_GRID_F_CNTRL	E86 - Enable grid frequency control	0	1	0		1
EN_PWM_SYNCH	E87 - Enable PWM synchronization	0	1	0		1
EN_PV_SWEEP	E89 - Enable PV sweep	Range		0		1
		0	No			
		1	Automatic sweep (period=E64)			
		2	One-shot sweep			
EN_REACT_PWR_CTRL_FP	E90 - Enable automatic reactive power control according to cosfi=f(P) curve	Range		0		1
		0	No			
		1	Variable Cosphi			
EN_REACT_PWR_CTRL_FV	E91 - Enable automatic reactive power control according to Q=f(V) curve	Range		0		1
		0	No			
		1	Variable Cosphi			
EN_ACT_PWR_CTRL_FF	E92 - Enable automatic active power control according to P=f(F) curve	0	1	0		1
		2	Fixed Cosphi			
EN_GRID_CONN_MANAGE	E93 - Enable grid connection manage	Range		0		1

		0	No			
		1	CEI 0-21 function (Italy)			
		2	CGC/GF004 function (China)			
		Range				
		0	No			
		1	Ext. active power limitation	0		1
		2	Ext. reactive power limitation			
		3	Ext. active and reactive power limitation			
EN_LVFRT_MANAGE	E95 - Enable LVFRT manage	1	0	0		1
EN_AI_FCN	E96 - Enable Anti Islanding function	1	0	0		1
EN_V_DROP_COMP	E97 - Enable compensation for LCL filter voltage drop	1	0	0		1
EN_ACT_PWR_CTRL_PV	E98 - Enable automatic active power control according to P(V) curve	1	0	0		1
EN_ID_COMP	E210 - Enable Id compensation	0	1	0		1

3.3 APPLICATION INTERNAL VALUES

Name	Description	u.m.	Scale
V_OC	D64 - PV Open Circuit Voltage	V	1
I _{pv}	D65 - PV current	A	32
P _{pv}	D66 - PV power	kW	32
P _{pv} _NORM_COEFF	D68 - P _{pv} normalization coefficient	kW	16
Stato	D69 - Status		1
P _{ac}	D70 - AC Power	kW	128
I _q	D71 - Active current I _q filtered	% I_CONV_NOM	40.96
I _d	D72 - Reactive current I _d filtered	% I_CONV_NOM	40.96
T _{amb}	D73 - Ambient temperature	°C	1
Energy_Wh	D74 - Produced Energy in Wh	Wh	1
Energy_kWh	D75 - Produced Energy in kWh	kWh	1
Energy_MWh	D76 - Produced Energy in MWh	MWh	1
Energy_GWh	D77 - Produced energy in GWh	GWh	1
EN_AUT_START	D78 - Enable automatic start		1
APLL_STATUS_WORD	D79 - Application status word		1
APPL_ALL_WORD	D80 - Application alarm word		1
PWM_SYNC_DELAY	D81 - PWM SYNC delay	µs	10
S_NOM	D82 - Nominal Apparent Power	kVA	16
I_TA	D83 - TA current	A	16
V _{grid} _CONN_MANAGE	D86 - V _{grid} reading for Grid Connection Manage	% V_GRID_NOM	1000
F _{grid} _CONN_MANAGE	D87 - F _{grid} reading for Grid Connection Manage	% F_GRID_NOM	1000
Count_GRID_FAULT	D88 - Counter for A4.0 after Grid Fault event	s	1
Count_SPI	D89 - Counter for A4.0 after SPI trigger event	s	1
PRC_DC_BUS_REF_FLDBUS	D90 - Fieldbus DC Bus reference	% DC_BUS_REF	163.84
I _q _REF_FLDBUS	D91 - Fieldbus I _q active current reference	% I_CONV_NOM	163.84
I _d _REF_FLDBUS	D92 - Fieldbus I _d reactive current reference	% I_CONV_NOM	163.84
PRC_CONV_I_PEAK_FLDBUS	D93 - Fieldbus current limit	% I_CONV_NOM	163.84
V_GRID_OVD_FLDBUS	D94 - Fieldbus V _{grid} override reference	% V_GRID_ISL	163.84
FREQ_OVD_FLDBUS	D95 - Fieldbus F _{grid} override reference	% F_GRID_NOM	163.84
VB_LIM_MAX_OVD_FLDBUS	D96 - Fieldbus maximum DC Bus voltage limit override	% VB_MAX	163.84
VB_LIM_MIN_OVD_FLDBUS	D97 - Fieldbus minimum DC Bus voltage limit override	% VB_MIN	163.84
P_GRID_REF_FLDBUS	D98 - Fieldbus active power reference	% S_NOM	163.84
Q_GRID_REF_FLDBUS	D99 - Fieldbus reactive power reference	% S_NOM	163.84

3.4 APPLICATION EXTRA PARAMETERS

Name	Description	Min	Max	Def	u.m.	Scale
CTRL_PF_LOCK_OUT_WAIT_TIME	E200 - P(f) Lock-out waiting time	0	900	300	s	1
CTRL_PF_RAMP_TIME	E201 - P(f) active power ramp time	1	900	300	s	1
CTRL_PF_F_LOCK_IN_UF	E202 - Lock-in frequency of P=f(F) curve in Under Frequency	45.00	49.70	55.00		100
CTRL_PF_SLOPE_UF	E203 - Percege Slope of P=f(F) curve in Over Frequency	0.1	5.0	1.2	% GRID_FREQ_NOM / % P_INST	10
CTRL_PF_F_LOCK_OUT_OF	E204 - Lock-out frequency of P=f(F) curve in Over Frequency	50.05	51.00	50.10	Hz	100
CTRL_PF_F_LOCK_OUT_UF	E205 - Lock-out frequency of P=f(F) curve in Under Frequency	49.00	49.95	49.90	Hz	100
STOP_RAMP_TIME	E206 - Stop ramp time	1	900	10	s	1
CTRL_PV_RAMP_TIME	E207 - P(V) active power ramp time	1	900	300	s	1
EN_ID_COMP	E210 - Enable Id compensation	0	1	0		1
I_TA_NOM	E211 - TA (current sensor) rated current	0.0	2000.0	0.0	A	10
OFFSET_TA_U	E212 - TA (current sensor) phase U offset	-100.00	100.00	0.00	%	100
OFFSET_TA_W	E213 - TA (current sensor) phase W offset	-100.00	100.00	0.00	%	100
TA_ANG_SUM	E214 - TA (current sensor) sum angle	-179.9	180.0	0.0	°	10
I_TA_FILTER	E215 - TA (current sensor) filter time constant	0.0	999.9	100.0	ms	10
Q_POS_RAMP_UP_TIME	E245 - Reactive power ramp up time with Q>0	0	900	0	s/S_NOM	1
Q_POS_RAMP_DOWN_TIME	E246 - Reactive power ramp down time with Q>0	0	900	0	s/S_NOM	1
Q_NEG_RAMP_UP_TIME	E247 - Reactive power ramp up time with Q<0	0	900	0	s/S_NOM	1
Q_NEG_RAMP_DOWN_TIME	E248 - Reactive power ramp down time with Q<0	0	900	0	s/S_NOM	1

3.5 APPLICATION OSCILLOSCOPE VALUES AND ANALOG OUTPUTS

The internal quantities for the oscilloscope and analog outputs of this application are as follows:

Output	Internal variable assigned	u.m.	Scale
osc68	Vbus_rif	100% = 900V	40.96
osc69	Pac_mio_norm	100% = 1,732*P62*P63	40.96
osc70	Pin_k	100% = 1,732*P62*P63	40.96
osc71	dP	100% = 1,732*P62*P63	40.96
osc72	Rapp	100%	40.96
osc73	contatore_LVFRT	ms	1
osc74	lpv_filt	% I_PV_MAX	40.96
osc75	Ppv_norm	100% = Ppv_norm_coef = D68	40.96
osc76	dV		40.96
osc77	PRC_lq_filt	% I_CONV_NOM	40.96
osc78			163.84
osc79	STATUS	-	1
osc80	wr_err	% F_GRID_NOM	163.84
osc81	err_f	% F_GRID_NOM	163.84
osc82	Id_AI_sf	% I_CONV_NOM	163.84
osc83	Id_AI_filt	% I_CONV_NOM	163.84
osc84	Iqref_abs	% I_CONV_NOM	163.84
osc85	Id_Alv	% I_CONV_NOM	163.84
osc86	P active limit	% S_NOM	40.96
osc87	I_TA_U	% I_TA_NOM	327.68
osc88	I_TA_W	% I_TA_NOM	327.68
osc89	Iq_TA_to_AFE_prc	% I_CONV_NOM	40.96
osc90	Id_TA_to_AFE_prc	% I_CONV_NOM	40.96
osc91	Iq_TA_to_AFE_prc_filt	% I_CONV_NOM	40.96
osc92	Id_TA_to_AFE_prc_filt	% I_CONV_NOM	40.96
osc93	I_TA_module	% I_CONV_NOM	40.96
osc94	presenza_LVFRT	(bool)	1
osc95	IP	(bool)	1
osc96	GRID_FAULT_CORE	(bool)	1
osc97	OD_ON_GRID	(bool)	1
osc98	GRID_FAULT_APPL	(bool)	1
osc99	RUN_APPL	(bool)	1

3.6 APPLICATION LOGIC INPUTS

Input	Name	Description	Applications involved		
			PV (E26=1)	Wind or Hydro	ESS (E25=1)
I00	ID_RUN	Run command	✓	✓	✓
I02	ID_EN_EXT	External enable	✓	✓	✓
I08	ID_RESET_ALR	Reset alarms	✓	✓	✓
I13	ID_EN_INS_PREC	Enable power soft start	✓	✓	✓
I14	ID_EN_FLDBUS_REF	Enable FIELD-BUS reference values	✓	✓	✓
I22	ID_EXT_START	External Start	✓	-	-
I23	ID_EXT_STOP	External Stop	✓	-	-
I24	ID_BLK_MEM_I_SPD	Freeze PI voltage regulator integral memory	✓	✓	✓
I25	ID_STOP_RAMP	Enable stopping ramp	-	-	✓
I26	ID_PWM_SYNCH	PWM Synchronization input	✓	✓	✓
I27	ID_SPD_OK	Surge Protection Device OK	✓	-	-
I28	ID_DISP_INT_CLOSE	Grid contactor close AND line fuse OK	✓	-	-
I29	ID_FAN_OK	Fan OK	✓	-	-
I30	ID_PV_OK	PV switch close AND PV insulation OK	✓	-	-
I31	ID_PROT_INT_OK	Interface protection OK	✓	-	-

I00 – Run command

Connect to this input a selector to enable the start sequence. If input is high then the run of converter is enabled, if low, the converter doesn't accept the run command. If input goes low during the run, converter will immediately stop.

I14 – Enable FIELD-BUS reference values

I22 – External Start

In case of PV application (E26=1), this input has the same function of run button on the remote keypad, refer to par. 7.2.

I23 – External Stop

In case of PV application (E26=1), this input has the same function of stop button on the remote keypad, refer to par. 7.2.

I25 – Enable stopping ramp

In case of ESS application (E25=1), this input activate a stopping ramp re

I26 – PWM Synchronization input

Input used to synchronize the PWM pulses of the AFE with that of another converter, refer to par. 4.13.

I27 – Surge protection device OK

Is it possible to connect to this input the signalling contacts of surge protection device that would be present on DC side or on AC side

I28 – Grid contactor close AND line fuse OK

This input is used to verify the closure of on-grid contactor and the status of line fuses put in series with the contactor (if presents). The closure of contactor correspond to an high logic level.

I29 – Fan OK

This input is used to signal any failure of cabinet fans. A low logic level indicates a fault presence.

I30 – PV switch close AND PV insulation OK

This input is used to verify the status of PV breaker and the status of an insulation control device (CI) that could be present on PV side. A low logic level indicates the closure of PV breaker and the absence of alarms on CI.

I31 – Interface protection OK

This input is used to verify the status of the Interface Protection Device (SPI). A low logic level indicates no alarms on the SPI.

3.7 APPLICATION LOGIC OUTPUTS

Output	Name	Description	Applications involved		
			PV (E26=1)	Wind or Hydro	ESS (E25=1)
O32	OD_EN_AFE_FAN	Enable AFE fan	✓	✓	✓
O33	OD_ON_GRID	On-Grid contactor command	✓	✓	✓
O34	OD_SGANCIO_FV	PV breaking switch (unmanaged)	✓	-	-
O35	OD_APPL_FAULT_1	Application Fault 1	✓	-	-
O36	OD_P_ACTIVE_LIMIT	Active power limitation	✓	✓	✓
O37	OD_IDC_OC	Idc overcurrent	✓	✓	✓
O38	OD_CP	Cosphi(P) function active	-	✓	✓
O39	OD_QV	Q(V) function active	-	✓	✓
O40	OD_PF	P(F) function active	-	✓	✓
O41	OD_PV	P(V) function active	-	✓	✓
O42	OD_STOP_RAMP	Stopping ramp active	-	✓	✓
O44	OD_DCBUS_OK	DC Bus voltage higher than $P62 \cdot \sqrt{2} \cdot 1,1$	-	✓	✓

O32 – Enable AFE fan

This digital output allows the AFE converter fan to be turned on based on the radiator temperature. The fan turn-on temperature can be set via parameter **E47-TEMP_ON_AFE_FAN**.

Once on, the fan will turn off automatically when the radiator temperature drops below the preset threshold, i.e. E47-10°C.

O33 – On-grid contactor command

This digital output allows the opening/closing of the grid contactor.

O34 – PV breaking switch

Not managed.

O35 – Application Fault 1

This digital output signals fault conditions that can occur at the level of internal components of the cabinet, which have nothing to do with the AFE converter. In particular, this output is set in any of the following circumstances:

- 1) if the surge protection devices on the PV side have failed (see LI1); or
- 2) if the minimum threshold of the insulation resistance set in the insulation controller on the PV side (see LI4) is exceeded and the photovoltaic voltage is $V_{pv} > 170V$; or
- 3) if the magnetic-thermal breaker of the cabinet fan (see LI5) has tripped; or
- 4) if there are problems with the interface protection (see LI3), for instance, because the grid, voltage and frequency parameters are not within the limits set in the interface protection; or
- 5) if, when you try to close the grid contactor (see LO3) it does not close due to it being stuck or due to blown line fuses.

O36 – Active power limitation

Indicates that the active power limit is active and that the value (D84 and osc86) is below 100%.

O37 – Idc overcurrent

Indicates that the DC current component on phase U, V, or W has exceeded the threshold E223 or E240.

O38 – Cosphi(P) function active

Indicates the activation (Lock-in) of Cosphi(P) function.

O39 – Q(V) function active

Indicates the activation (Lock-in) of Q(V) function.

O40 – P(F) function active

Indicates the activation (Lock-in) of P(f) function.

O41 – P(V) function active

Indicates the activation (Lock-in) of P(V) function.

O42 – Stopping ramp active

Indicates that the execution of the stopping ramp related to I25-ID_STOP_RAMP.


O44 – DC Bus voltage higher than $P62 \cdot \sqrt{2} \cdot 1,1$

Indicates that the DC Bus voltage D24 is higher than $P62 \cdot \sqrt{2} \cdot 1,1$.

3.8 STATUS WORD

3.8.1 Core status word

The status variable of the AFE core sw is available on the fieldbus, hereinafter the meaning of the most important bit:



3.8.2 Application status word

The internal value **D79-APPL_STATUS_WORD** represents the PV state machine status word. Below the meaning of the bits.

Bit	Significato
0÷4	PV state machine status = D69
5	RUN_APPL

Where RUN_APPL is an internal variable that commands the AFE run and that is activated automatically by the software when the machine moves through the different operating status.

3.9 APPLICATION ALARM WORD

The internal variable **D80-APPL_ALARM_WORD** represents the application alarm words in case of PV application. Below the meaning of the bits.

Bit	Significato
0	Not (ID_PROT_INT_OK)
1	Not (ID_SPD_OK)
2	ALL_PV_INS
3	Not (ID_FAN_OK)
4	ALL_TL_ON_GRID_OR_GRID_FUSES
5	GRID_FAULT_APPL

Where:

- ALL_PV_INS := (Vpv>170V) and (not(ID_PV_OK))
- ALL_TL_ON_GRID_OR_GRID_FUSES := OD_ON_GRID and (not(ID_DISP_INT_CLOSE))
- GRID_FAULT_APPL := GRID_FAULT_CORE or ERR_FREQ

GRID_FAULT CORE is the A02 AFE alarm grid-off.

ERR_FREQ is an alarm of the application that triggers if the frequency is bigger than the limit set on E50-PERC_GRID_F_CNTRL (the ERR_FREQ alarm triggers only if E86-EN_GRID_F_CNTRL=1).


4 OPERATION

4.1 CAPABILITY

The OPDE AFE Energy is a four quadrant AC/DC converter that is suitable to be used for different P-Q capabilities (i.e. the working area in the plane P-Q). Some capabilities are described below.


4.1.1 Capability for Wind/Hydro

In the figures that follow, the capability is indicated with the shaded area. The choice of the capability influences the execution of some functions described later - $Q(V)$, $\cos\phi(P)$ - hence is important to set properly some parameter as indicated below.




E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	0,90
E28 - P_REGEN_MAX	N/A
E29 - P_ABSORPT_MAX	N/A

Figure 1 – Rectangular capability with $\cos\phi_n=0,9$




E18 - I_ACT_NOM	95%
E62 - CTRL_CP_QV_COSPHI	0,95
E28 - P_REGEN_MAX	N/A
E29 - P_ABSORPT_MAX	N/A

Figure 2 – Rectangular capability with $\cos\phi_n=0,95$



E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	0,90
E28 - P_REGEN_MAX	N/A
E29 - P_ABSORPT_MAX	N/A

Figure 3 – Rounded rectangular capability with $\cos\phi_n=0,9$




E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	0,90
E28 - P_REGEN_MAX	N/A
E29 - P_ABSORPT_MAX	N/A

Figure 4 – Semicircular capability


4.1.2 Capability for ESS

In the figures that follow, the capability is indicated with the shaded area. The choice of the capability influences the execution of some functions described later - $Q(V)$, $\cos\phi(P)$ - hence is important to set properly some parameter as indicated below.




E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	$\cos\phi_n$
E28 - P_REGEN_MAX	$P_{S_{MAX}}$
E29 - P_ABSORPT_MAX	$P_{C_{MAX}}$

Figure 5 – Circular cut capability




E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	$\cos\phi_n$
E28 - P_REGEN_MAX	$P_{S_{MAX}}$
E29 - P_ABSORPT_MAX	$P_{C_{MAX}}$

Figure 6 – Circular asymmetric cut capability



E18 - I_ACT_NOM	<100%
E62 - CTRL_CP_QV_COSPHI	$\cos\phi_n$
E28 - P_REGEN_MAX	$P_{S_{MAX}}$
E29 - P_ABSORPT_MAX	$P_{C_{MAX}}$

Figure 7 – Circular cut capability limited



E18 - I_ACT_NOM	100%
E62 - CTRL_CP_QV_COSPHI	0,90
E28 - P_REGEN_MAX	$P_{S_{MAX}}$
E29 - P_ABSORPT_MAX	$P_{C_{MAX}}$

Figure 8 – Rectangular capability

4.2 APPLICATION SELECTION

The OPDE_Energy application sw is suitable for different applications. Some specific parameters must be set according to the application, as depicted in the table below.

Application	E25 EN_CURR_REF	E26 APPL_SEL	C00 CONTROL_SEL	I20 VSI/CSI_CTRL
Photovoltaic	0-No	1-Solar	0-AFE standard control	disregard
Rotating machine connected to AC/DC inverter (wind/hydro)	0-No	0-AFE_STD	0-AFE standard control	disregard
Electrical Storage System	1-Yes	0-AFE_STD	2-Micro-Grid control	1-PLL active

With parameter **E26-APPL_SEL** it's possible to choose between two mode of operation:

- E26 = 0-AFE_STD → This selection disable the state machine dedicated to the photovoltaic application and works with the DC-Bus voltage regulation, similar to a standard AFE. Use this setting in case of application with rotating machine connected to a AC/DC inverter (for example wind or hydroelectric application), or in case of Electrical Storage System (ESS).
- E26 = 1-Solar → This selection enable the photovoltaic state machine. Use in case of photovoltaic application.

With parameter **E25-EN_CURR_REF** it's possible to disable the DC-Bus voltage control loop: the converter works with active/reactive current reference and active/reactive power reference.

- E25 = 0-No → This selection disable leave the DC-Bus voltage control loop enabled. Use when it's required to regulate the DC-Bus voltage (photovoltaic and hydro/wind).
- E25 = 1-Yes → This selection disable the DC-Bus voltage control loop, the AFE can accept active/reactive current reference and active/reactive power reference. Use this settings in case of Electrical Storage System (ESS).



If E25-EN_CURR_REF=1 the OPDE_Energy recognizes that the AFE is working in a ESS and automatically adapts the working mode of many of the functions described in chapters below::

- Grid Connection Requirements
- Active Power Control P(F)
- Active Power Control P(V)
- Reactive Power Control Cosphi(P)
- Reactive Power Control Q(V)

For further information refer to the following paragraphs.

4.3 OPERATING SEQUENCES (ONLY WITH E26=1)

This section describes the converter operating sequences in case of a photovoltaic application (**E26-APPL_SEL = 1**). The state machine diagram is as follows:




Figure 9 – State Machine Diagram

The inverter start-up sequence depends on some parameters that control the repetition times for the start-up attempts and the minimum power required for starting the unit.

The parameters and internal quantities involved in this function are the following ones:

Name	Description	Min	Max	Def	u.m.	Scale
P_START_MIN	E41 - Minimum power for starting sequence	0	100	2	% Ppv_NORM_COEFF	1
DELTA_V_PMIN	E42 - Delta V for minimum power measure	0	100	70	V	1
V_PV_START	E43 - PV voltage for starting sequence	380	780	460	V	1
T1_PMIN	E44 - Repetition time T1 of minimum power measurement	0.1	10.0	1.0	min	10
T2_PMIN	E45 - Repetition time T1 of minimum power measurement T2>T1	0.1	30.0	10.0	min	10
Ton_1	E46 - Waiting time Ton_1	0.1	10.0	0.1	min	10
STATUS	D69 - State machine status	-	-	-	-	1
EN_AUT_START	D78 - Enable automatic start	-	-	-	-	1

D69	State machine status
0	Off
1	Stand-by
2	Connecting mode
3	Grid Mode
4	Maintenance
5	Init MPPT & P_MIN control
7	Minimum Power Wait Mode
8	PV sweep
9	Vmppt ramp

The different operating statuses are described in detail hereafter.

4.3.1 Off Status [0]

When the converter is first powered up, it is in OFF status, disconnected from the mains (grid) and not in “run” mode. To change the converter to the run mode you will need to press the start button on the remote keypad; this will switch the converter to the STAND-BY mode [1].

NOTE Whichever the status of the converter, pressing the stop button will stop the converter and return it to the OFF mode.

If you wish to manage the start and stop commands remotely, you can assign logic inputs **I23–EXTERNAL_START** and **I24–EXTERNAL_STOP** to the free digital inputs LI7 and LI8, and then connect normally open pushbuttons to the relevant digital inputs.

The start and stop commands can also be issued via field bus (Modbus, CanOpen, Profibus) by writing the word corresponding to the digital inputs.

After receiving the start command, the converter will switch from OFF to STAND-BY mode [1].

When issued, the start command remains stored. This means that the converter will not return automatically to OFF [0]. In fact, in case of mains voltage failure or PV voltage failure, the converter will switch to the STAND-BY mode [1]. Once the mains and PV parameters are back to correct values, the converter will switch automatically to the next status.

The internal quantity **D78–EN_AUT_START** indicates that the start command has been stored.

NOTE The start command will be enabled only if digital input **I01–Run command** is at high logic level, otherwise the command will be ignored (in the diagrams shown in Section 2, digital input I01 is assigned to physical input LI2).

4.3.2 Stand-By Status [1]

In this mode, the converter monitors the PV voltage to see whether it exceeds the value set in **E43–V_PV_START**. If this is verified, then the converter waits for a time equal to **E46–Ton_1** and then switches to CONNECTING MODE [2].

4.3.3 Connecting Mode Status [2]

In this mode, the converter attempts to connect to the mains by closing the on-grid contactor. This command is performed by logic output **O33–OD_ON_GRID**, which switches to high (in the diagrams shown in section 2, output O33 is assigned to digital output LO3).

When logic output **O33** is high, it will be verified that:

- 1) the contactor has closed, by checking digital input **I28–ID_DISP_INT_CLOSE** (in the diagrams shown in Section 2, digital input I28 is assigned to physical input LI6);
- 2) the grid is OK (that is, the grid present signal is there and the grid frequency control, if enabled, is not signalling a problem).

If the above is verified, then the converter will switch to INIT MPPT & PMIN CONTROL [5].

If the converter sees that:

- $V_{pv} < 375V$; or that
- after 2 sec the grid is not OK (which means that either the grid fault alarm or grid frequency not OK alarm, if enabled, have been triggered);

it will switch to STAND-BY mode [1].

4.3.4 Init MPPT & PMIN Control Status [5]

The converter measures the no-load voltage of the photovoltaic field and displays it on the internal quantity **D64–V_OC**, it then starts running, regulating the PV voltage to a value indicated hereinafter as V_{PV_PMIN} , which is equal to:

$$V_{PV_PMIN} = V_{OC} - DELTA_V_PMIN$$

where **DELTA_V_PMIN = E42** is a user settable parameter.

At this point, the converter measures the power on the PV side in % with respect to **D68–Ppv_NORM_COEFF**. If it exceeds the threshold set in **E41–P_START_MIN**, then the converter will switch to GRID_MODE, otherwise it means that the power measured does not exceed the minimum set point and the converter will go into MINIMUM POWER WAIT MODE [7].

D68 is equal to:

$$D68 - Ppv_NORM_COEFF = V_MPPT_MIN \cdot I_PV_MAX$$

where I_{PV_MAX} depends on the size, as indicated in the table below.

AFE Energy Size	V_MPPT_MIN	I_PV_MAX	Ppv_NORM_COEFF
OPDE S 7	380 V	7,3 A	2,77 kW
OPDE S 15		15,6 A	5,92 kW
OPDE S 22		23,2 A	8,81 kW
OPDE S 32		33,7 A	12,8 kW
OPDE S 48		50,3 A	19,1 kW
OPDE S 60		62,9 A	23,9 kW
OPDE S 70	460 V	83 A	38,2 kW
OPDE S 90		107 A	49,2 kW
OPDE S 110		113 A	52,0 kW
OPDE S 150		157 A	72,2 kW
OPDE S 175		202 A	92,9 kW
OPDE S 220		258 A	118,7 kW
OPDE S 250		293 A	134,8 kW
OPDE S 310		361 A	166,1 kW
OPDE S 370		430 A	197,8 kW
OPDE S 460		498 A	229,1 kW

4.3.5 Grid Mode Status [3]

The converter enables either function:

- automatic MPPT if E80–EN_MPPT=1 and E81–EN_MANUAL_MPPT=0, or
- manual MPPT if E80–EN_MPPT=1 and E81–EN_MANUAL_MPPT=1

When “automatic MPPT” is enabled, the converter regulates the PV voltage by operating about its maximum power point, by applying a P&O algorithm according to the following parameters:

- E35–DELTA_V** Voltage step MPPT Algorithm [V]
- E36–TIME_STEP** Time step MPPT Algorithm [Tpwm]

When “manual MPPT” is enabled, the converter adjusts the PV voltage according to a fixed voltage given by parameter **E39–K_MANUAL_MPPT**, which defines the operating voltage as a % of the open circuit voltage (Voc) measured in the INIT MPPT & PMIN Control mode [5].

For further details about MPPT see Section 4.2.

4.3.6 Minimum Power Wait Mode Status [7]

In this mode, the converter remains connected to the mains and performs three attempts to measure the minimum start power, spaced apart by a time delay interval set in parameter **E44–T1_PMIN**. If the power measured exceeds the threshold value, then the converter will switch to GRID MODE [3].

If both attempts fail, the converter will go into STAND-BY mode [1], i.e. it disconnects from the mains and waits for the time set in **E45–T2_PMIN** before it restarts the sequence.

4.3.7 PV Sweep Status [8]

In status [8] the inverter is executing the PV sweep function. If parameter **E89–EN_PV_SWEEP=1–Automatic sweep** or **E89–EN_PV_SWEEP=2–One-shot sweep** Refer to par. 0 for an explanation of the function.

4.3.8 Vmppt ramp [9]

In status [9] the inverter have just finished the PV sweep and moves the Vpv voltage to reach with a ramp the Vmppt value calculated in status [8].

4.3.9 Maintenance Status [4]

You can perform maintenance tasks by running the converter while disconnected from the PV field. To switch to maintenance mode, set the converter to OFF [0] and then E82=1. For further details see Section 4.7

4.4 LOCKING OF THE CONVERTER (ONLY WITH E26=1)

In specific alarm situations, the converter automatically switch off and goes on status OFF [0]. This happens if there is one of this events:

- AFE core alarm;
- **I01–Run command** input at low logic level;
- **I27–Surge protection device OK** input at low logic level;
- **I29–F an OK** input at low logic level;

- **I30–PV switch close and PV insulation OK** input at low logic level;
- **I31–Interface protection OK** input at low logic level;
- Ambient temperature higher than the threshold set in E48 (only with ambient temperature control function activated).

4.5 MPPT FUNCTION (ONLY WITH E26=1)

4.5.1 Manual MPPT

By acting on parameter **E81–EN_MANUAL_MPPT** the inverter works with a fixed and constant photovoltaic voltage (Vpv). To enable this function set:

E81=1 (yes) E80=0 (no)

The value of the Vpv regulated voltage can be set by acting on parameter **E39–K_MANUAL_MPPT**, which determines the operating voltage as a percentage of the open circuit voltage (Voc) measured on the first daily power up of the inverter.

$$V_{pv} = K_MANUAL_MPPT \cdot V_{oc} = P239 \cdot d64$$

Each time the run command is issued, the inverter will measure the open circuit voltage (Voc) of the photovoltaic field and so it will re-calculate the Vpv operating voltage.

4.5.2 Automatic MPPT

If automatic MPPT is enabled, the inverter will automatically track the maximum power point of the photovoltaic field by applying a P&O (Perturb-and-Observe) algorithm. To enable automatic MPPT act on parameter **E80–EN_MPPT**, as follows:

E80=1 (yes) E81=0 (no)

By acting on parameters **E35** and **E36** you can modify the dynamic behaviour of MPPT.

E35–DELTA_V represents the width of the DC-Bus voltage change, in Volts, which the P&O algorithm performs while tracking the MPPT, whereas **E36–TIME_STEP** is the repetition frequency of the perturbations in multiples of the PWM period.

NOTE Do not change these parameter settings. Contact TDE MACNO for information if you wish to perform any calibrations.

4.5.3 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_MPPT	E80 - Enable MPPT Algorithm	0	1	1		1
DELTA_V	E35 - Voltage step MPPT Algorithm	0	20	3	V	1
TIME_STEP	E36 - Time step MPPT Algorithm	0	19999	5000	Tpwm	1
EN_MANUAL_MPPT	E81 - Enable Manual MPPT Algorithm	0	1	0		1
K_MANUAL_MPPT	E39 - MPP in % respect Voc measured	70	100	80	%Voc	1
V_OC	D64 - PV Open Circuit Voltage				V	1

4.6 GRID FREQUENCY CONTROL FUNCTION (ONLY WITH E26=1)

By setting **E86–EN_GRID_F_CNTRL** to 1, a control function for the grid frequency read by the AFE is enabled. In particular, the converter verify if the frequency is within the range specified in **E50–PERC_GRID_F_CNTRL**. The window within which no alarm will be generated concerning the grid frequency is the following one:

$$F_{RETE_MIN} \leq F_{RETE} \leq F_{RETE_MAX}$$

where

$$F_{RETE_MIN} = P63 \cdot \frac{100 + P250}{100} \quad F_{RETE_MAX} = P63 \cdot \frac{100 - P250}{100}$$

If the frequency reading exceeds the threshold value by more than 40 ms, then an alarm will be generated.

4.6.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_GRID_F_CNTRL	E86 - Enable grid frequency control	0	1	0		1
PERC_GRID_F_CNTRL	E50 - Percentage tolerance for grid frequency control	0.6	10	1	%	10

4.7 MAINTENANCE FUNCTION (ONLY WITH E26=1)

For the commissioning and maintenance of the system, a “maintenance” mode is provided, which makes it possible to run the converter in the absence of a photovoltaic field.

ATTENTION To enable the “maintenance” mode you must make sure that the disconnecter on the PV side is open, in order to prevent the PV field from being supplied a voltage that can damage the panels.

To enable this function, set **E82-EN_MANUT** to 1. When you do so, the inverter will automatically switch output **O33-OD_ON_GRID** to high. In this way, the DC-Bus capacitors will be precharged from the mains and the converter will connect to the power mains. Now you can start and stop the converter using the relevant pushbuttons on the remote keypad.

While it is “running”, the converter will regulate the DC-Bus voltage according to the voltage set in **P08-DC_BUS_REF**.

To exit the “maintenance” mode, set **E82-EN_MANUT** back to 0.

While E82=1, make sure not to save the parameters on EEPROM, otherwise this value will be saved and the inverter will always go into maintenance mode.

4.7.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_MANUT	E82 - Enable maintenance mode	0	1	0		1

4.8 AMBIENT TEMPERATURE CONTROL FUNCTION (ONLY WITH E26=1)

It is possible to stop the converter if the ambient temperature read via input PTC/NTC exceeds a threshold value settable in **E85-TEMP_AMB_OFF**. To use this function, you will need to connect a temperature probe model Epcos B57703M103G to terminal block M4, on terminal M4-1 and M4-2.

This function can be enabled through parameter **E85-EN_TEMP_OFF**. The ambient temperature reading is displayed in the internal quantity **D73-Tamb**.

4.8.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_TEMP_OFF	E85 - Enable temperature controlled switch-off	0	1	0		1
TEMP_AMB_OFF	E48 - AFE switch off ambient temperature	30	50	41	°C	1
Tamb	D73 - Ambient temperature	-	-	-	°C	1

4.9 AC POWER MEASUREMENT – CALCULATION OF PRODUCED ENERGY

The converter is able to calculate the energy production by using the output power measurement on the AC side. The resulting datum is an estimate and, therefore, subject to some degree of error.

In fact, the calculation of AC power, though precise, may not be accurate, because it depends on several factors, such as reactance and transformer losses, which differ depending of the size and construction of the equipment. Therefore, such losses are merely an estimate.

The instantaneous power injected into the grid is displayed in internal quantity **D70-AC power**. There is a correction parameter **E49-Kmult_Pac** that acts as a multiplication coefficient and allows the correction of the AC power reading, so that this value is as close as possible to the real value, thus enabling a correct calculation of the energy production.

The energy output is displayed in internal quantities D74, D75, D76, D77, which show the energy broken down in multiples of Wh, kWh, MWh and GWh respectively. The overall energy is the sum of these four contributions.

The Energy count can be zeroed by setting parameter **E83-ENERGY_RESET** to 1, after which the parameter will return automatically to 0.

4.9.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
Kmult_Pac	E49 - Pac measured multiplication coefficient	0	1	0		1
ENERGY_RESET	E83 - Reset produced energy counter	0	1	0		1
Pac	D70 - AC Power	0.00	-	-	kW	128
Energy_Wh	D74 - Produced Energy in Wh	0	999	-	Wh	1
Energy_kWh	D75 - Produced Energy in kWh	0	999	-	kWh	1
Energy_MWh	D76 - Produced Energy in MWh	0	999	-	MWh	1
Energy_GWh	D77 - Produced Energy in GWh	0	999	-	GWh	1

4.10 MANAGING THE INTERFACE PROTECTION

In many Countries, for being allowed to connect to the power mains and inject energy into it, a system must comply with specific technical regulations. In Italy, these regulations impose a duty to use an interface device (DDI) between the photovoltaic system and the public utility network (namely, the Enel distribution network) in order to disconnect the two systems in case of failure or malfunction of the distribution network. The DDI is controlled by the interface protection system (SPI), a device that monitors the mains voltage and frequency and sends an alarm signal when these parameters exceed the protection device settings. Normally, this alarm is signalled via a clean contact.

The OPDE_Energy Application allows the management of a SPI, the SPI status contact must be connected to logic input **I31-Interface protection OK**.

Moreover, the grid-connection regulations require that the contact of the SPI cuts directly the power supply of the DDI control coil.

4.11 CURRENT REFERENCE

With parameter **E25-EN_CURR_REF=1-Yes** it's possible to disable the DC-Bus voltage loop control and enable only the current loop control.

Use **E00-IQ_REF** and **E01-ID_REF** to give the active and reactive current references.

The active sign convention is used, i.e. the current toward the grid is considered positive.

A *positive* value in E00 means that active current flows from the AFE to the grid.

A *negative* value in E00 means that active current flows from the grid to the AFE

A *positive* value in E01 means the current produced can compensate inductive loads (**AFE acts as a capacitor**).

A *negative* value in E01 means the current produced can compensate capacitive loads (**AFE acts as an inductor**).

4.11.1 Function Parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_CURR_REF	E25 - Enable application current reference	0	1	0		1
IQ_REF	E00 - Reference for active current Iq	-100.00	100.00	0	% I_CONV_NOM	100
ID_REF	E01 - Reference for reactive current Id	-100.00	100.00	0	% I_CONV_NOM	100

4.12 FIELDBUS REFERENCE AND LIMIT

With parameter **E27-EN_FLDBUS_REF=Yes** it's possible to enable the fieldbus reference.

4.12.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_FLDBUS_REF	E27 - Enable FIELD-BUS reference values	0	1	0		1
PRC_DC_BUS_REF_FLDBUS	D90 - Fieldbus DC-Bus Reference				% DC_BUS_REF	163.84
IQ_REF_FLDBUS	D91 - Fieldbus Iq active current reference				% I_CONV_NOM	163.84
ID_REF_FLDBUS	D92 - Fieldbus Id reactive current reference				% I_CONV_NOM	163.84
PRC_CONV_I_PEAK_FLDBUS	D93 - Fieldbus current limit				% I_CONV_NOM	163.84
V_GRID_OVD_FLDBUS	D94 - Fieldbus Vgrid override reference				% V_GRID_ISL	163.84
FREQ_OVD_FLDBUS	D95 - Fieldbus Fgrid override reference				% F_GRID_NOM	163.84
VB_LIM_MAX_OVD_FLDBUS	D96 - Fieldbus maximum DC Bus voltage limit override				% VB_MAX	163.84
VB_LIM_MIN_OVD_FLDBUS	D97 - Fieldbus minimum DC Bus voltage limit override				% VB_MIN	163.84
P_GRID_REF_FLDBUS	D98 - Fieldbus active power reference				% S_NOM	163.84
Q_GRID_REF_FLDBUS	D99 - Fieldbus reactive power reference				% S_NOM	163.84

4.13 PWM SYNCHRONIZATION

In application where there is an AFE-Inverter system, or in application with many AFE working together in the same power plants, there is the possibility to synchronize the converter at PWM level. To do this it's necessary to connect the converter as shown below. **Errore. L'origine riferimento non è stata trovata..**




Figure 10 – Connections for PWM Synchronization

Parameter **E87-EN_PWM_SYNC** is used to select the drive function:

- a) E87=1-Master → Physical output n° 3 (P.O.3) is configured like “O31-PWM synchronization output”.
- b) E87=2-Slave → Physical Input n° 8 (P.I.8) is configured like “I26-PWM synchronization input”.

In the slave there is a tracking loop with gain Kp (P11) e Ta (P12). It's possible to set also the phase between master and slave with parameter E88.

Note1: Master and slave have to be set with the same PWM frequency (P101)

Note2: If the PWM frequency is great than 5kHz is necessary to use a pull-down 1kΩ resistance 1W.

4.13.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_PWM_SYNC	E87 - Enable PWM synchronization	Scale		0		1
		0	No			
		1	Master			
		2	Slave			
PWM_SYNC_PHASE	E88 - PWM synchronization angle	-175.0	175.0	0	Degrees	10
PWM_SYNC_DELAY	D81 - PWM SYNC delay	-400.0	400.0	0.0	µs	10

4.14 ACTIVE POWER CONTROL P(F)

With P(F) function is possible to:

- limit the active power P in case of grid over-frequency (OF), or
- control the active power P in case of grid over-frequency (OF) and under-frequency (UF).

The working mode depends on the value of parameter E25-EN_CURR_REF that identify if the application is an ESS or a PV/Hydro/Wind. The P control in OF and UF is enabled only for ESS, in the other cases the P is *limited*.

To enable the function set E92-EN_ACT_PWR_CTRL_PF=1 or 2. The table below describes the different working mode of P(F) function, further details in the following paragraphs.

Application	E25-EN_CURR_REF	E92-EN_ACT_PWR_CTRL_PF	P(F) working mode		
			limit/control	OF/UF	Block at Pmin
PV	0-No	0-No	not activated	-	-
		1-Yes, with power blocked at Pmin	P limit	OF	No
		2-Yes, without power blocked at Pmin			Yes
Hydro/Wind	0-No	0-No	not activated	-	-
		1-Yes, with power blocked at Pmin	P limit	OF	No
		2-Yes, without power blocked at Pmin			Yes
ESS	1-Yes	0-No	not activated	-	-
		1-Yes, with power blocked at Pmin	P control	OF and UF	No
		2-Yes, without power blocked at Pmin			Yes

4.14.1 P(F) for PV and Wind/Hydro

In a PV or Wind/Hydro application, the P(F) function *limits* the active power injected in the grid in case of a grid over frequency event. The control rule is depicted in the Figure below.




Figure 11 – Active power reduction in over frequency

The function is activated (Lock-in) when the frequency increase over threshold E02-CTRL_FF_F_LOCK_IN_OF. In lock-in status, if frequency increases more and more, the instantaneous power P_i decreases linearly, depending on the slope set in E03-CTRL_FF_SLOPE_OF.

If later the grid frequency decreases, the behaviour depends on selection done with E92-EN_ACT_PWR_CTRL_PF:

E92=1 - Yes, with power blocked at Pmin

The active power will be limited to the minimum value reached during the over frequency event (Pmin). If the frequency stays stable in the interval fixed by E205-CTRL_PF_F_LCOK_OUT_UF and E204-CTRL_PF_F_LCOK_OUT_OF (default interval is 50±1Hz) for a minimum continuous time equal to E200-CTRL_PF_LOCK_OUT_WAIT_TIME (default time is 300s), the function is deactivated (Lock-out).

After this 300s waiting time, the active power limit return to $P_{i_{max}}$ following a linear ramp with a slope equal to 20%* $P_{i_{max}}$ /min or, in any case, not less than 5%* P_{nom} /min.

When the power limit reaches $P_{i_{max}}$, the linear ramp continuous with the same slope until 100% power limit is reached.

E92=2 Yes, without power blocked at Pmin

The P(F) curve is executed backward, on the opposite direction, and the power is increased.

The activation (Lock-in) of P(F) function is signalled on digital output **O40–P(F) function active**. The value of the power limit is written in variable **D84–P_active_limit** or **osc86 – P_active_limit**, with scale 4096 and u.m [% D82–S_NOM].

For further information about the active power limitation management in Full Converter system refer to paragraph 5.1.

4.14.2 P(F) for ESS

In an Energy Storage System, the P(F) function *controls* the active power injected in the grid in case of a grid over/under frequency event. The active power reference that is set by the “User” and that was executed before the over/under frequency event is ignored and a new active power set-point generated by the P(F) function is used. The control rule is depicted in the Figure below.




Figure 12 – Active power regulation in over and under frequency for ESS

The function is activated (Lock-in) when:

- the frequency increases over threshold **E02–CTRL_FF_F_LOCK_IN_OF** that means an *OF lock-in*, or
- the frequency decreases under the threshold **E202–CTRL_FF_F_LOCK_IN_UF** that means an *UF lock-in*.

An activation time delay can be set with **E99–CTRL_PF_DELAY_ON**.

In *OF lock-in* status, if frequency increases more and more, the instantaneous power P_i decreases linearly, depending on the slope set in **E03–CTRL_FF_SLOPE_OF**. In *UF lock-in* status, if frequency decreases more and more, the instantaneous power P_i increases linearly, depending on the slope set in **E203–CTRL_FF_SLOPE_UF**.

If we have a *OF lock-in/UF lock-in* and later the grid frequency decreases/increases, the behaviour depends on selection done with **E92–EN_ACT_PWR_CTRL_PF**:

E92=1 - Yes, with power blocked at P_{min}

The active power will be limited to the minimum/maximum value reached during the over/under frequency event (P_{min}). If the frequency stays stable in the interval fixed by **E205–CTRL_PF_F_LCOK_OUT_UF** and **E204–CTRL_PF_F_LCOK_OUT_OF** (default interval is 50 ± 1 Hz) for a minimum continuous time equal to **E200–CTRL_PF_LOCK_OUT_WAIT_TIME** (default time is 300s), the function is deactivated (Lock-out).

After this 300s waiting time, the active power value return to the User active power reference following a linear ramp with a slope equal to **E201–CTRL_PF_RAMP_TIME**. When the power limit reaches the Users set point the P(F) function is deactivated

E92=2 Yes, without power blocked at P_{min}

The P(F) curve is executed backward, on the opposite direction, and the power is increased/decreased linearly, without any waiting time or ramp.

The activation (Lock-in) of P(F) function is signalled on digital output **O40–P(F) function active**.

4.14.3 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_ACT_PWR_CTRL_PF	E92 - Enable automatic active power control according to P=f(F) curve	Range		0		1
		0	No			
		1	Yes, with power blocked at Pmin			
		2	Yes, without power blocked at Pmin			
CTRL_PF_F_LOCK_IN_OF	E02 - Lock-in frequency of P=f(F) curve in Over Frequency	45.00	55.00	50.30	Hz	100
CTRL_PF_F_LOCK_IN_UF	E202 - Lock-in frequency of P=f(F) curve in Under Frequency	45.00	49.70	55.00		100
CTRL_PF_SLOPE_OF	E03 - Percentage Slope of P=f(F) curve in Under Frequency	0.1	5.0	2.4	% GRID_FREQ_NOM / % P_INST	10
CTRL_PF_SLOPE_UF	E203 - Percentage Slope of P=f(F) curve in Over Frequency	0.1	5.0	1.2	% GRID_FREQ_NOM / % P_INST	10
CTRL_PF_F_LOCK_OUT_OF	E204 - Lock-out frequency of P=f(F) curve in Over Frequency	50.05	51.00	50.10	Hz	100
CTRL_PF_F_LOCK_OUT_UF	E205 - Lock-out frequency of P=f(F) curve in Under Frequency	49.00	49.95	49.90	Hz	100
CTRL_PF_LOCK_OUT_WAIT_TIME	E200 - P(f) Lock-out waiting time	0	900	300	s	1
CTRL_PF_DELAY_ON	E99 - Activation delay timed of P=f(F) curve	0.00	10.00	0.00	s	100
CTRL_PF_RAMP_TIME	E201 - P(f) active power ramp time	1	900	300	s	1

4.15 ACTIVE POWER CONTROL P(V)

With P(V) function it's possible to limit/control the active power in case of a grid over-voltage. Set **E98-EN_ACT_PWR_CTRL_PV=1-Yes** to enable this function.

If parameter **E25-EN_CURR_REF=0-No**, that identify PV/Hydro/Wind application, then the P(V) function works as a *P limit*. If parameter **E25-EN_CURR_REF=1-Yes**, that identify if the application is an ESS, then the P(V) function works as a *P control*.

Application	E25-EN_CURR_REF	E98-EN_ACT_PWR_CTRL_PV	P(F) working mode
PV/Hydro/Wind	0-No	0-No	not activated
		1-Yes	P limit
ESS	1-Yes	0-No	not activated
		1-Yes	P control

4.15.1 P(V) for PV and Wind/Hydro

In case of PV or Wind/Hydro application the P(V) function limits the active power according to Figure 13. When the grid voltage increases over the threshold **E74-CTRL_PV_V1S**, the power is automatically limited with a linear characteristic that decreases the power to a minimum value equal to **E76-CTRL_PV_P_LIM** at voltage **E75-CTRL_PV_V2S**. When the voltage decrease, the P(V) characteristic is executed in the opposite way and will stop at the current power value.

The activation (Lock-in) of P(V) function is signalled on digital output **O41 – P(V) function active**.




Figure 13 – P(V) characteristic for PV/Hydro/Wind

4.15.2 P(V) for ESS

In an Energy Storage System, the P(V) function *controls* the active power injected in the grid in case of a grid over voltage event.

The P(V) function activates when the grid voltage increases over the threshold **E74-CTRL_PV_V1S**. The active power reference that is set by the “User” is ignored and a new active power set-point generated by the P(V) function is used.

The new reference has a linear characteristic that starts from the instantaneous power P_i down to a value equal to **E76-CTRL_PV_P_LIM** at voltage **E75-CTRL_PV_V2S**, and is generated through a ramp settable with **E207-CTRL_PV_RAMP_TIME**.

The control rule is depicted in the Figure 14.

When the voltage decrease, the P(V) characteristic is executed in the opposite way and stops automatically when it reaches the input power reference value.

The activation (Lock-in) of P(V) function is signalled on digital output **O41 – P(V) function active**.




Figure 14 - P(V) characteristic for ESS

4.15.3 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_ACT_PWR_CTRL_PV	E98 - Enable automatic active power control according to P(V) curve	0	1	0		1
CTRL_PV_V1S	E74 - V1S voltage of P(V) curve	108	135	108	% V_GRID_NOM	1
CTRL_PV_V2S	E75 - V2S voltage of P(V) curve	110	135	110	% V_GRID_NOM	1
CTRL_PV_P_LIM	E76 - Active power limit for P(V) curve	0	200	20	% P_ACT_NOM	1
CTRL_PV_RAMP_TIME	E207 - P(V) active power ramp time	1	900	300	s	1

4.16 GRID CONNECTION REQUIREMENTS

With parameter **E93-EN_GRID_CONN_MANAGE** it's possible to enable the management of the grid connection according to the Italian Standard CEI 0-21 or to the Chinese standard CGC/GF004.

The voltage and frequency values used for this function come from “osc46-Grid Voltage” and “osc44-Grid Freq”, later filtered with an LPF filter with time constant E13. The values are shown in:

D86-Vgrid_CONN_MANAGE

D87-Fgrid_CONN_MANAGE

4.16.1 CEI 0-21 operating mode (E93=1)

If **E93=1** the CEI 0-21 operating mode is activated. The connection to the grid is done only if:

- the grid voltage filtered (**D86-Vgrid_CONN_MANAGE**) is between **E05-V_GRID_MIN** and **E04-V_GRID_MAX** (default interval is 85% - 110% of nominal voltage P62); and

- b) the grid frequency filtered (**D87-Fgrid_CONN_MANAGE**) is between **E07-F_GRID_MIN** and **E06-F_GRID_MAX** (default interval is 49,90 Hz – 50,10 Hz);
- for a minimum time set in **E08-GRID_WAI_TIME_1** (default time 30s); and
- c) the protection interface (PI) status signal - connected to input **I31-Interface protection ok** - is at high level.

If the inverter execute a connection after a disconnection caused by the interface protection (PI), then the waiting time is equal to **E09-GRID_WAIT_TIME_2**¹.

The counter related to **E08-GRID_WAIT_TIME_1** is displayed in **D88 – Counter_GRID_FAULT**.
The counter related to **E09-GRID_WAIT_TIME_2** is displayed in **D89 – Counter_SPI**.

Alarm “**A4.0 – Waiting time for grid voltage and frequency control**” is shown:

- a) when input **I31-Interface protection ok** is at low level; or
- b) when the inverter is not connected to the grid; or
- c) when the inverter is connected to the grid but Vgrid or Fgrid are out of the acceptance thresholds, or
- d) when voltage and frequency have the right value but the waiting time is not ended.

After the waiting time, the power increases with a linear ramp whose slope is fixed by **E10-ACT_PWR_RAMP_TIME**.
The value of the power limit is written in variable **D84-P_active_limit** or **osc86 – P_active_limit**, with scale 4096 and u.m [% **D82-S_NOM**].

When the inverter is running it continuously monitors the grid voltage and frequency. If:

- a) the grid voltage is outside the range **E05-V_GRID_MIN** and **E04-V_GRID_MAX** (default interval is 85% - 110% of nominal voltage); or
- b) the grid frequency is outside the range **E12-F_GRID_MIN_RUN** and **E11-F_GRID_MAX_RUN** (default interval is 47,50 Hz – 51,50 Hz);

then it stops and gives alarm **A4.0**.

4.16.2 CGC/GF004 operating mode (E93=2)

If **E93=2** the CGC/GF004 operating mode is activated. In this case the response to grid frequency is depicted below.

Frequency range	Response of inverter
$F_{grid} < E12-F_GRID_MIN_RUN$	The inverter stops operating within 0,2s and disconnect from the grid. At that moment, if the frequency is back to normal value, the inverter automatically connects to the grid and start to operate.
$E12-F_GRID_MIN_RUN < F_{grid} < E07-F_GRID_MIN$	The inverter operates for a time equal to E09-GRID_WAIT_TIME_2 , then stops. At that moment, if the frequency is back to normal value, the inverter automatically connects to the grid and start to operate.
$E07-F_GRID_MIN < F_{grid} < E06-F_GRID_MAX$	The inverter operates normally
$E06-F_GRID_MAX < F_{grid} < E11-F_GRID_MAX_RUN$	The inverter operates for a time equal to E08-GRID_WAIT_TIME_1 , then stops. Alarm “ A4.2-Grid Over Frequency during run ” is shown At that moment, if the frequency is back to normal value, the inverter doesn't automatically start to operate. A reset command is needed.
$F_{grid} > E11-F_GRID_MAX_RUN$	The inverter stops operating within 0,2s Alarm “ A4.2-Grid Over Frequency during run ” is shown At that moment, if the frequency is back to normal value, the inverter doesn't automatically start to operate. A reset command is needed.
$E05-V_GRID_MIN < V_{grid} < E04-V_GRID_MAX$	The inverter operates normally
$E05-V_GRID_MIN < V_{grid}$	The inverter stops operating within 0,2s Alarm “ A4.3- Grid Over/Under Voltage during run ” is shown At that moment, if the frequency is back to normal value, the inverter doesn't automatically start to operate. A reset command is needed.
$V_{grid} < E04-V_GRID_MAX$	The inverter stops operating within 0,2s Alarm “ A4.3- Grid Over/Under Voltage during run ” is shown At that moment, if the frequency is back to normal value, the inverter doesn't automatically start to operate. A reset command is needed.

Default values for Chinese standard CGC/GF004 are:

E06=50,2Hz E07=49,5Hz E11=50,5Hz E12=48Hz E08=120s E09=600s

¹ The PI tripping is recognized only if the AFE remains powered during the grid fault, for example using an external UPS to generate the 24 Vdc power supply.

4.16.3 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_GRID_CONN_MANAGE	E93 - Enable grid connection manage	Range		0		1
		0	No			
		1	CEI 0-21 function (Italy)			
		2	CGC/GF004 function (China)			
V_GRID_MAX	E04 - Maximum grid voltage for enabling grid connection	101	120	110	% V_GRID_NOM	1
V_GRID_MIN	E05 - Minimum grid voltage for enabling grid connection	80	99	85	% V_GRID_NOM	1
F_GRID_MAX	E06 - Maximum grid frequency for enabling grid connection	50.05	50.10	51.00	Hz	100
F_GRID_MIN	E07 - Minimum grid frequency for enabling grid connection	49.00	49.95	49.90	Hz	100
GRID_WAIT_TIME_1	E08 - Wait time for enabling grid connection	1	900	30	s	1
GRID_WAIT_TIME_2	E09 - Wait time for enabling grid connection after SPI trigger or over frequency	1	900	300	s	1
ACT_PWR_RAMP_TIME	E10 - Active power ramp time	1	900	300	s/S_NOM	1
F_GRID_MAX_RUN	E11 - Maximum grid frequency for running	50.05	54.00	51.50	Hz	100
F_GRID_MIN_RUN	E12 - Minimum grid frequency for running	46.00	49.95	47.50	Hz	100
V_F_GRID_FILTER	E13 - Vgrid and Fgrid filter time constant	0	999	100	ms	1
GRID_UNB_MAX	E17 - Maximum grid voltage unbalance for enabling run	0.0	100.0	10.0	% V_GRID_NOM	10
V_GRID_MAX_UNB	E31 - Maximum grid voltage with unbalanced grid for enabling run	0.0	200.0	115.0	% V_GRID_NOM	10
V_GRID_MIN_UNB	E32 - Minimum grid voltage with unbalanced grid for enabling run	0.0	200.0	80.0	% V_GRID_NOM	10
Vgrid_CONN_MANAGE	D86 - Vgrid reading for Grid Connection Manage function				% V_GRID_NOM	1000
Fgrid_CONN_MANAGE	D87 - Fgrid reading for Grid Connection Manage function				% F_GRID_NOM	1000
Count_GRID_FAULT	D88 - Counter for A4.0 after Grid Fault event				s	1
Count_SPI	D89 - Counter for A4.0 after SPI trigger event				s	1

4.17 REACTIVE POWER CONTROL Q(V)

4.17.1 Q(V) for PV and Wind/Hydro

The $Q=f(V)$ function injects reactive power Q into the grid in case of a grid over/under voltage event. The control rule is depicted in Figure 15.




Figure 15 – $Q=f(V)$ curves for PV/Hydro/Wind type a) left, type b) right

The convention is:

- Inductive = reactive power absorbed from the grid, as an inductor. The inverter current is leading with the grid voltage, with passive sign convention. Reactive power $Q < 0$.
- Capacitive = reactive power injected in the grid, as a capacitor. The inverter current is lagging with the grid voltage, with passive sign convention. Reactive power $Q > 0$.

Using parameter **E90-EN_REACT_PWR_CTRL_FV** it's possible to choose two different regulation curves for the $Q=f(V)$ function, as depicted in Figure 15:

- E90=0-No → $Q=f(V)$ disabled
- E90=1-Variable Q → Q is a function of the active power P: type a) curve.
- E90=2-Fixed Q → Q is fixed and settable: type b) curve.

For **type a)** curve, the function is activated (Lock-in) when:

- The grid voltage exceeds the threshold **E66-CTRL_FV_V1S** or decreases under the threshold **E68-CTRL_FV_V1I**; and
- the active power P exceeds the power threshold fixed by parameter **E70-CTRL_FV_PWR_LOCK_IN**.

If at least one of this conditions is not satisfied, the inverter injects power into the grid with $\cos\phi=1$.

For **type b)** curve, the function is activated (Lock-in) when:

- The grid voltage exceeds the threshold **E67-CTRL_FV_V2S** or decreases under the threshold **E69-CTRL_FV_V2I**; and
- the active power P exceeds the power threshold fixed by parameter **E70-CTRL_FV_PWR_LOCK_IN**.

If at least one of this conditions is not satisfied, the inverter injects power into the grid with $\cos\phi=1$.

The function is deactivated (Lock-out) when:

- the active power decrease under the threshold **E71-CTRL_FV_PWR_LOCK_OUT**; or
- the voltage is between the range **E66-CTRL_FV_V1S** $< V_{grid} <$ **E68-CTRL_FV_V1I**

The activation (Lock-in) of $Q(V)$ function is signalled on digital output **O39 – Q(V) function active**.

4.17.2 Q(V) for ESS

In an Energy Storage System, the $Q(V)$ is that of Figure 16, that is similar to the previous one with an extra parameter **E78-CTRL_QV_K** that can be used to fix the reactive current at a value different from 0 during the Lock-out.




Figure 16 – $Q=f(V)$ curve for ESS

4.17.3 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
		Scale				
EN_REACT_PWR_CTRL_QV	E91 - Enable automatic reactive power control according to Q=f(V) curve	0	No	0		1
		1	Variable Q			
		2	Fixed Q			
CTRL_FP_FV_COSPHI	E62 - Cosphi of point C $\cos\phi=f(P)$ curve and $\cos\phi$ of Q=f(V) curve	0.00	1.00	0.90		100
CTRL_FV_V1S	E66 - V1S voltage of Q=f(V) curve	80	120	108	% V_GRID_NOM	1
CTRL_FV_V2S	E67 - V2S voltage of Q=f(V) curve	80	120	110	% V_GRID_NOM	1
CTRL_FV_V1I	E68 - V1I voltage of Q=f(V) curve	80	120	92	% V_GRID_NOM	1
CTRL_FV_V2I	E69 - V2I voltage of Q=f(V) curve	80	120	90	% V_GRID_NOM	1
CTRL_FV_PWR_LOCK_IN_REG	E70 - Lock-in power of Q=f(V) curve during regeneration	0	100	20	% P_ACT_NOM	
CTRL_FV_PWR_LOCK_OUT	E71 - Lock-out power of Q=f(V) curve	0	50	100	% P_ACT_NOM	1
CTRL_FV_PWR_LOCK_IN_ABS	E77 - Lock-in power of Q=f(V) curve during absorption	-100	0	-20	% P_ACT_NOM	1
CTRL_QV_K	E78 - K factor of Q=f(V) curve	-1.00	1.00	0.00	% S_NOM	100
CTRL_QV_DELAY_ON	E79 - Activation delay time of Q=f(V) curve	0	30	3	s	1

4.18 REACTIVE POWER CONTROL $\cos\phi=f(P)$

The function $\cos\phi=f(P)$ injects reactive power into the grid in case of a grid over voltage event. The goal of the function is to limit the grid over voltage caused by the active power injected by the inverter into the grid. The control rule is depicted in Figure 17.




Figure 17 – $\cos\phi=f(P)$ curve and modification, defined using three points

The convention is:

- Inductive = reactive power absorbed from the grid, as an inductor. The inverter current is leading with the grid voltage, with passive sign convention. Reactive power $Q < 0$.
- Capacitive = reactive power injected in the grid, as a capacitor. The inverter current is lagging with the grid voltage, with passive sign convention. Reactive power $Q > 0$.

Using parameter **E90-EN_REACT_PWR_CTRL_FP** it's possible to choose two different regulation curves for the $\cos\phi=f(P)$ function, as depicted in Figure 17:

- E90=1-Variable $\cos\phi$ → $\cos\phi$ is a function of the active power P: type a) curve.
- E90=1-Fixed $\cos\phi$ → $\cos\phi$ is fixed and settable: type b) curve.

With parameters E60, E61 it's possible to modify the active power value associated to point A and B of the type a) curve. With parameter E62 it's possible to set the $\cos\phi$ for point C of the type a) curve.

The function is activated (Lock-in) when:

- the working point P/Pn exceeds the power threshold fixed by parameter **E61-CTRL_FP_PWR_B**; and
- the grid voltage increases over threshold **E63-CTRL_FP_V_LOCK_IN**.

If at least one of this conditions is not satisfied, the inverter injects power into the grid with $\cos\phi=1$.

During the lock-in, the inverter injects the reactive current necessary to reach the working point fixed by Figure 8 depending on the actual active power level.

The function is deactivated (Lock-out) when:

- the active power decreases under the power threshold **E61-CTRL_FP_PWR_B**, or
- the voltage grid decreases under the lock-out value **E64-CTRL_FP_V_LOCK_OUT**.

The activation (Lock-in) of $\cos\phi(P)$ function is signalled on digital output **O38 – Cosphi(P) function active**.

4.18.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_REACT_PWR_CTRL_CP	E90 - Enable automatic reactive power control according to $\cos\phi=f(P)$ curve	Range		0		1
		0	No			
		1	Variable Cosphi			
		2	Fixed Cosphi			
CTRL_CP_PWR_A	E60 - Power of point A $\cos\phi=f(P)$ curve	0	100	20	% P_ACT_NOM	1
CTRL_CP_PWR_B	E61 - Power of point B $\cos\phi=f(P)$ curve	0	100	50	% P_ACT_NOM	1
CTRL_CP_QV_COSPHI	E62 - Cosphi of point C $\cos\phi=f(P)$ curve and $\cos\phi$ of $Q=f(V)$ curve	0.00	1.00	0.90		100
CTRL_CP_V_LOCK_IN	E63 - Lock-in voltage of $\cos\phi=f(P)$ curve	100	100	105	% V_GRID_NOM	1
CTRL_CP_V_LOCK_OUT	E64 - Lock-out voltage of $\cos\phi=f(P)$ curve	90	90	100	% V_GRID_NOM	1

4.19 REACTIVE POWER Q RAMP (E25=0)

When E25-EN_CURR_REF=0 a ramp block can be enabled in the reactive current reference, i.e. reference generated from:

- E01-ID_REF
- $\cos\phi(P)$ function (E90)
- Q(V) function (E91)
- External command (E94)

4.19.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
Q_POS_RAMP_UP_TIME	E245 - Reactive power ramp up time with $Q>0$	0	900		s/S_NOM	1
Q_POS_RAMP_DOWN_TIME	E246 - Reactive power ramp down time with $Q>0$	0	900	0	s/S_NOM	1
Q_NEG_RAMP_UP_TIME	E247 - Reactive power ramp up time with $Q<0$	0	900	0	s/S_NOM	1
Q_NEG_RAMP_DOWN_TIME	E248 - Reactive power ramp down time with $Q<0$	0	900	0	s/S_NOM	1

4.20 THERMAL PROTECTION

Using logic output “**O32-Enable AFE fans**”, it’s possible to switch on and off the internal fans of the converter AFE. For the connections refer to Figure 18.

Logic output O32 will move to logic level:

- High → when the heatsink temperature read in internal value D25 increase over the threshold **E47-TEMP_ON_AFE_FAN**;
- Low → when the heatsink temperature read in internal value D25 decrease under the value E47-10°C.




Figure 18 – Connections for the thermal control of internal AFE fans

4.20.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
TEMP_ON_AFE_FAN	E47 – O32 switch on temperature of AFE fans	30	80	60	°C	1

4.21 EXTERNAL COMMANDS

With parameter E94 it's possible to enable the external commands. External commands are parameters:

- E40–EXT_ACT_PWR_LIM → used to limit the active power injected into the grid
- E19–EXT_Q_GRID_REF → used to give a reactive power reference (E19>0 is for Q<0 inductive, E19<0 is for Q>0 capacitive).

4.21.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
		Range				
EN_EXT_CMND	E94 - Enable external commands	0	No	0		1
		1	Ext. active power limitation			
		2	Ext. reactive power limitation			
		3	Ext. active and reactive power limitation			
EXT_ACT_PWR_LIM	E40 - External active power limit	0	100	100	% P_ACT_NOM	10
EXT_Q_GRID_REF	E19 - External grid reactive power (Q) reference	-100.00	100.00	0	% P_ACT_MAX	1000
S_NOM	D82 - Nominal Apparent Power				kVA	10

4.22 ANTI ISLANDING FUNCTION

The Anti Islanding (AI) function is intended to avoid the happening of islanding situations that could occur when the grid voltage switch off and there is an equilibrium in the power coming from inverter through loads, together with the resonance frequency of the loads that is near to the grid nominal frequency so that the 3-phase voltage could persists even if the grid is switched off.

To enable the function use parameter **E96–EN_AI_FCN**. When the function is active, a little reactive current is injected on the grid as an overlapped noise component. This reactive current is used to move the frequency in the case of islanding situations.

When the error frequency is greater than **E20-THR_ER_FRQ_ALL**, alarm **A4.1-Anti-Islanding frequency error** is generated and output O33-On-grid contactor command moves to low logic level. In fact, with E96=1 output O33 becomes:

$$O33 = O33 \text{ AND } (\text{NOT } (A4.1))$$

4.22.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_AI_FCN	E96 - Enable Anti Islanding function	0	1	0		1
THR_ERR_FRQ_ALL	E20 - Error Frequency Threshold for alarm	0.0	10.0	10.0	% GRID_FREQ_NOM	10
KAI	E21 - AI_Proportional gain for error frequency filtered	-100.0	100.0	10.0		10
FT_LOWPASS	E22 - AI_Cut Frequency Low Pass Filter	1.00	30.00	10.00	Hz	100
FT_HIGHPASS	E23 - AI_Cut Frequency High Pass Filter	0.01	10.00	0.50	Hz	100

4.23 VOLTAGE DROP COMPENSATION

With the voltage drop compensation function it's possible to obtain a more accurate adjustment of the cosphi measured at the top of the transformer, on 400Vac side. This function compensate the voltage drop and the voltage phase shift introduced by the 400/270 transformer (and/or by the secondary inductance of the LCL filter).

To enable the function use parameter **E97-E_V_DROP_COMP**.

Parameter **E14-K_TRANSF** is used to set the transformer turn ratio. For the transformer it's considered to have a star-star connection hence with no phase-shift. In case of delta-star connection, the phase-shift introduced by the transformer must be put into parameter P75 summing it or subtracting it to the default value P75=4° already set into P75.

The inductance and the resistor of the transformer must be put into parameter **E15-PRC_DELTA_VLT** and **E16-PRC_DELTA_VRT**.

4.23.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_V_DROP_COMP	E97 - Enable compensation for LCL filter voltage drop	0	1	0		1
K_TRANSF	E14 - Transformer turns ratio	67.50	0.01	100.00		100
PRC_DELTA_VLT	E15 - Voltage drop due to transformer inductance	0.01	100.00	2.00	% V_GRID_NOM	100
PRC_DELTA_VRT	E16 - Voltage drop due to transformer resistor	0.01	100.00	0.50	% V_GRID_NOM	100

4.24 LVFRT

The LVFRT manage function gives the possibility to comply to the LVFRT requirements depicted in the Italian standard CEI 0-21. To enable the LVFRT manage use parameter **E95-EN_LVFRT_MANAGE**.

The (V-t) characteristic that is implemented is rectangular as depicted in Figure 19, and can be set using parameters **P50-MIN_V_GRID**, **E72-LVFRT_T_MAX** as described in the following.

This rectangular settable (V-t) characteristic is suitable to comply with a lot of different (V-t) characteristics specified into the national standards. All the (V-t) characteristics with a shape that can be placed inside the rectangle are manageable.

Some example of (V-t) characteristic that can be managed are depicted in Figures 9, 10, 11.




Figure 19 – LVFRT (v-t) characteristic




Figure 20 – “CEI 0-16;V1:2013-12” (V-t) characteristic for static generator




Figure 21 – “CEI 0-16;V1:2013-12” (V-t) characteristic for wind generator




Figure 22 – “Terna, Allegato A17” (V-t) characteristic for wind generator

By default this function is not active, therefore in case of a grid voltage drop the inverter will automatically disconnect from the grid opening the grid main contactor. The disconnection is done because the grid voltage decreases under the threshold **P50-MIN_V_GRID**.

When the function is activated (E95=Yes), if there is a grid voltage drop with:

- $V_{grid} < P50-MIN_V_GRID$;
- voltage drop duration $< E72-LVFRT_T_MAX$;

then the inverter stops to supply power into the grid but doesn't disconnect from the grid, i.e. the grid contactor KM02 doesn't open and the inverter gives alarm “A02.0 – Alarms for grid fault / sequence of phase L1, L2, L2 not connected”.

If within the maximum waiting time set in E72 there is a voltage grid restoration, then the inverter automatically resets and comes back to run after the waiting time set in **P65-WaitAfeReady**.

If within the maximum waiting time set in E72 there is not a voltage grid restoration, then at the end of the waiting time the inverter disconnects from the grid by opening the grid main contactor KM02.

4.2.4.1 LVFRT hardware connection

When the LVFRT management is activated (E95=1), the main contactor KM01 and pre-charge contactor KM02 toward the grid must be controlled according to the indications on the AFE Energy installation manual, that are:

- Use of logic output “O33-ON-GRID CONTACTOR COMMAND” to allow the closing of KM01 even during the voltage fall;
- Power supply of AFE, KM01, KM02 from UPS;
- Adjustment of the interface protection (SPI) in order to avoid spurious tripping during the voltage drop.

Refer to AFE Energy installation manual for further details and schematics.

4.2.4.2 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_LVFRT_MANAGE	E95 - Enable LVFRT manage	0	1	0		1
LVFRT_T_MAX	E72 - LVFRT maximum duration	0.10	5.00	1.00	s	100
GRID_UNB_MAX	E17 - Maximum grid voltage unbalance for enabling run	0.0	100.0	10.0	% V_GRID_NOM	10
V_GRID_MAX_UNB	E31 - Maximum grid voltage with unbalanced grid for enabling run	0.0	200.0	115.0	% V_GRID_NOM	10
V_GRID_MIN_UNB	E32 - Minimum grid voltage with unbalanced grid for enabling run	0.0	200.0	80.0	% V_GRID_NOM	10
MIN_V_GRID	P50 - Alarm level for minimum grid voltage	5.0	95.0	70.0	% V_GRID_NOM	10

4.25 ENERGY AND POWER

4.25.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
Energy_Wh	D74 - Produced energy in Wh	0	999		Wh	1
Energy_kWh	D75 - Produced energy in kWh	0	999		kWh	1
Energy_MWh	D76 - Produced energy in MWh	0	999		MWh	1
Energy_GWh	D77 - Produced energy in GWh	0	999		GWh	1
ENERGY_RESET	E83 - Reset produced energy counter			No		1
Ppv_	D66 - PV power	kW				10
Ppv_NORM_COEFF_	D68 - Ppv normalization coefficient	kW				100
Pac	D70 - AC Power	kW				100
S_NOM	D82 - Nominal Apparent Power	kVA				10
Kmult_Pac	E49 - Kmult_Pac					10
COSPHI_NOM	E65 - Nominal Cosphi for definition of D82-S_NOM	0.00	0.00	0.90		100

4.26 DC INPUT

When the OPDE AFE Energy includes a current sensor on DC input, the measured DC current is displayed in **D65–PV current**, the current is considered positive if it comes into the + terminal. The Full Scale value of the current reading is defined in **E30–I_PV_MAX**, a low-pass filter with time constant **E37–Tau_lpv_filter** is used to filter the signal.

The DC power **D66–PV power** is calculated as:

$$D66 = D24 \cdot D65$$

4.26.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
I_PV_MAX	E30 - Maximum PV input current	0	999		A	10
Tau_lpv_filter	E37 - Time constant lpv filter	0	999	10	ms	1
DIS_lpv_filter	E208 – Disable lpv filter	Range		0		1
		0	No			
		1	Yes			
lpv_	D65 - PV current	0	999		A	32
Ppv_	D66 - PV power	0	999		kW	32
Ppv_NORM_COEFF_	D68 - Ppv normalization coefficient	0	999		kW	16

4.27 PV SWEEP (ONLY WITH E26=1)

The power curve of a PV plant in case of partially shadowing of one of the strings has more than one local maximum power point. Only one of this is the global maximum power point.




Figure 23 – Example of power curve in case of partially shadowing.

The global maximum is the local max 2

With the PV sweep function it's possible to identify this global maximum power point obtaining an increase efficiency of the MPPT algorithm avoiding that the MPPT tracks a maximum that is not the global maximum.

To activate the function set **E89-EN_PV_SWEEP=1-Automatic sweep**. The function execute a sweep of the characteristic V-I of the PV plants with a step change of the PV voltage from the Voc value down to the **E51-V_MPPT_MIN** value in a number of step equal to **E24-N_SAMPLE** executed with a period fixed by **E34-PV_SWEEP_REP_PERIOD**.

When the PV sweep function is executed, the MPPT algorithm is stopped. At the end of the sweep, the MPPT algorithm works again and starts from the voltage working point identified by the PV sweep function.

The voltage/current values measured by this function can be plotted in the PV_sweep page on OPDE Explorer, as below. Press the "Read" button under the chart to download and print the graphs.




Figure 24 – Example of I-V and P-V characteristics measured with the pv-sweep function

Furthermore, it's possible to force the execution of a single PV sweep independently of the automatic sweep functionality. This can be useful to verify the V-I and the V-P characteristics of the PV plant during the commissioning or during the maintenance operation executed periodically along the entire life-time of the PV plant.

To do this, first put the inverter on status [0] pushing the stop button. Then set **E89-EN_PV_SWEEP = 1-One-Shot sweep**. Doing this, the inverter connects to the grid (status[4]) and wait for the pushing of the run button. Pushing the run button, a single pv-sweep is executed and at the end of the sweep the inverter automatically stops, but stay connected to the grid.

After the single pv-sweep, it's possible to view the measured I-V and P-V characteristics on PV-sweep page on OPDE Explorer. A subsequent press of the run button, results in the execution of a new pv-sweep.

To disable the one-shot sweep, set **E89-EN_PV_SWEEP=0-No**, the inverter goes to status[0] and disconnects from the grid.

4.27.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_PV_SWEEP	E89 - Enable PV sweep	Range		0		1
		0	No			
		1	Automatic sweep			
		2	One-shot sweep			
N_SAMPLE	E24 - Number of samples for PV Sweep	10	50	10		1
PV_SWEEP_TIME_STEP	E33 - PV sweep time step	1	999	200	ms	1
PV_SWEEP_REP_PERIOD	E34 - PV sweep repetition period	1	180	60	min	1

4.28 Id COMPENSATION

The “Id compensation” function can be used to read and compensate the reactive current (Id) of a load (typically an asynchronous motor) connected to the same 3-phase grid where is connected the AFE. AC current transducers must be connected on phase U and W and read using optional card 4S0024 according to Figure 25. Load resistors for current transducers must be put in 4S0024 according to Figure 26.

For guidance on the choice of current transducer and load resistors please contact TDE Macno.




Figure 25 – Id compensation




Figure 26 – Id compensation: connection to 4S0024 board

4.28.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
EN_ID_COMP	E210 - Enable Id compensation	0	1	0		1
I_TA_NOM	E211 - TA (current sensor) rated current	0.0	2000.0	0.0	A	10
OFFSET_TA_U	E212 - TA (current sensor) phase U offset	-100.00	100.00	0.00	%	100
OFFSET_TA_W	E213 - TA (current sensor) phase W offset	-100.00	100.00	0.00	%	100
TA_ANG_SUM	E214 - TA (current sensor) sum angle	-179.9	180.0	0.0	°	10
I_TA_FILTER	E215 - TA (current sensor) filter time constant	0.0	999.9	100.0	ms	10
I_TA	D83 - TA current				A	10

4.29 GRID ISLAND CONTROL (ONLY WITH E25=1)

In an Energy Storage System the AFE works as an AC current generator (CSI) with the DC voltage controller disabled (E25=1) because the DC voltage is provided by the batteries.

In this working mode, an algorithm that limits the active current reference is automatically enabled to avoid that the DC voltage goes outside the voltage limits specified in parameters **E55-VB_MAX**, **E56-VB_MIN**.

4.29.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
VB_MAX	E55 - V Bus Max Limit in CSI	0.0	1200.0	0.0	V	10
VB_MIN	E56 - V Bus Min Limit in CSI	0.0	1200.0	0.0	V	10
KP_VB_LIM	E57 - Kp V Bus limit in CSI	0.0	300.0	1.0		10
Ti_VB_LIM	E58 - Ti V Bus Limit in CSI	0.0	3000.0	60.0	ms	10
Tf_VB_LIM	E59 - Tf V Bus Limit in CSI	0.0	3000.0	0.0	ms	10

4.30 STORAGE (ONLY WITH E25=1)

In an Energy Storage System the AFE works as an AC current generator (CSI). Active and reactive power references can be provided with parameters **E53-P_GRID_REF** and **E54-QGRID_REF**.

E28 and E29 are used to define the capability of the ESS, refer to par. 4.1.2.

4.30.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
P_REGEN_MAX	E28 - Maximum regeneration power	0.0	200.0	100.0	% S_NOM	10
P_ABSORPT_MAX	E29 - Maximum absorption power	-200.0	0.0	-100.0	% S_NOM	10
P_GRID_REF	E53 - Active power reference	-200.0	200.0	0.0	% S_NOM	10
Q_GRID_REF	E54 - Reactive power reference	-200.0	200.0	0.0	% S_NOM	10

4.31 TRANSFORMERLESS

The transformerless function (AFE Tless) limits the DC current injected toward the grid and can be used instead of the insulation transformer when the grid code requires to limit the DC current.

A current sensing module and an optional card 4S0024 must be connected according to Figure 27. The transformer must be replaced with a secondary inductance (refer to AFE Energy installation manual).

Logic output **O37-Idc overcurrent** is used to open the grid circuit breaker (DG) when the DC current on phase U, V, or W exceeds one of these thresholds:

- E223 - TLESS_IDC_THRa with Idc filter time constant E237-TLESS_LPF2a_TF, or
- E240 - TLESS_IDC_THRb with Idc filter time constant E238-TLESS_LPF2b_TF.

During the Idc overcurrent event the alarm **A4.5 – Idc overcurrent** is generated.

The status of O37 is equal to the status of alarm A4.5, therefore O37 stays at high logic level until alarm A4.5 is reset.

A derivative filter on the signal “osc11-current module” is used to recognize the AFE load transients, another derivative filter on the signal “osc44-frequency” is used to recognize transients that happens on the grid that are not coming from the AFE. These two derivative filter are used to disable the Idc overcurrent recognition during transient events.

To enable the AFE Tless function select **E216-EN_TLESS=1**, then execute the Rgrid tuning as described in paragraph 4.31.1.




Figure 27 – AFE Tless connection




Figure 28 – O37 connection for AFE Tless

4.31.1 Rgrid tuning

The Rgrid tuning function measures the resistance that the AFE sees toward the grid, this data is used to regulate automatically the proportional gain of the Tless function. During the tuning a reactive current must be injected into the grid, P68 is used to set temporarily this value, at the end of the tuning P68 must be restored at the original value.

Connect the AFE to the grid and verify that it's in stop with no alarm. Set **E225-EN_R_GRID_TUNING=1** and **P68=30%**. Drag and drop **E226-PRC_DELTA_VRG**, **E229-TLESS_IDC_U** in the monitor window on OPD Explorer.

Give run, after 5s the AFE will generate a DC ramping voltage on phase U that generates a DC current on phase U. The DC voltage ramp will stop when:

- the DC current on phase U reaches the +100% value, or
- the DC voltage reaches the maximum value equal to $E227 \cdot 5$.

After 5s the DC voltage go back to zero and the Rgrid measured value is written in E226.

During the test the value displayed in E229 will increase. The test is finished when E229 decreases back to approximately zero and E226 changes its value. At this moment is possible to remove the run command, E225 will automatically restore to 0.




Figure 29 – Rgrid tuning

4.31.2 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
		Range				
EN_TLESS	E216 - Enable Transformerless	0	No	0	-	1
		1	Yes			
TLESS_REG_KP	E217 - Kp Tless regulator gain	0.01	100.0	3.50	-	100
TLESS_REG_TI	E218 - Ti Tless regulator lead time constant	0.1	3000.0	50.0	ms	10
TLESS_REG_TF	E219 - Tf Tless regulator filter time constant	0.0	0.0	3000.0	ms	10
TLESS_NOTCH_F0	E220 - Tless Notch Filter natural frequency	0.0	100.0	50.0	Hz	10
TLESS_NOTCH_FB	E221 - Tless Notch Filter bandwidth	0.0	100.0	25.0	Hz	10
TLESS_NOTCH_DMP	E222 - Tless Notch filter damping factor	0.0	100.0	0.0	%	10
TLESS_IDC_THRa	E223 - Tless Idc threshold a	0.1	100.0	0.5	% I_CONV_NOM	10
TLESS_IDC_NOM	E224 - Tless Idc rated current	0.001	32.767	0.0	A	1000
EN_R_GRID_TUNING	E225 - Enable Rgrid tuning	Range		0	-	1
		0	No			
		1	Yes			
PRC_DELTA_VRG	E226 - Voltage drop due to total resistor toward the grid	0.01	100.00	10.00	%	100
TLESS_OFF_MAX	E227 - Tless maximum voltage offset	0.1	5.0	2.0	% V_CONV_NOM	10
TLESS_REG_MAX	E228 - Tless regulator maximum output	0	400	200	%	1
TLESS_IDC_U	E229 - Tless Idc U current	-	-	-	A	1000
TLESS_IDC_W	E230 - Tless Idc W current	-	-	-	A	1000
TLESS_DER_I_TF	E231 - Tless current derivative filter time constant	0.0	3000.0	10.0	ms	10
TLESS_DER_I_TD	E232 - Tless current derivative time constant	0.1	3000.0	20.0	ms	10
TLESS_DER_I_THR	E233 - Tless current derivative threshold	0.0	100.0	10.0	%	10
TLESS_DER_F_TF	E234 - Tless frequency derivative filter time constant	0.0	3000.0	10.0	ms	10
TLESS_DER_F_TD	E235 - Tless frequency derivative time constant	0.1	3000.0	200.0	ms	10
TLESS_DER_F_THR	E236 - Tless frequency derivative threshold	0.0	100.0	10.0	%	10
TLESS_LPF2a_TF	E237 - Tless LPF2a filter time constant	0.1	3000.0	200.0	ms	10
TLESS_LPF2b_TF	E238 - Tless LPF2b filter time constant	0.1	3000.0	25.0	ms	10
TLESS_LPF2_DMP	E239 - Tless LPF2a and LPF2b damping factor	0.01	1.00	0.90	-	100
TLESS_IDC_THRb	E240 - Tless Idc threshold b	0.1	999.9	1.0	A	10
TLESS_U_KP	E243 - Tless U amplitude compensation	0.0	200.0	100.0	%	10
TLESS_W_KP	E244 - Tless W amplitude compensation	0.0	200.0	100.0	%	10

4.32 CYCLIC

The AFE on-board PLC has a cyclic task with a period settable with E241-CYCLICPERIOD.

4.32.1 Function parameters

Name	Description	Min	Max	Def	u.m.	Scale
CYCLICPERIOD	E241 - Cyclic period duration	0.2	10.0	1.0	ms	10

4.33 AUTOMATIC ALARM RESET (ONLY WITH E26=1)

The automatic alarm reset function, automatically resets the AFE if there is an active alarm and the AFE is in Off Status (D69-STATUS=0). In the presence of an active alarm with Status=0, the automatic reset command is continuously repeated with a period given by E73-RES_REP_TIME.

Alarm "A02.0-Alarms for grid fault / sequence of phase L1, L2, L3 not connected" and "A4.3-Grid Over Frequency" are not automatically reset.

4.34 MAPPED OBJECT - FIELDBUS OBJECT DICTIONARY

The AFE core sw has its own default mapped variable, they are listed in the table below (for detailed information refer to the **Fieldbus Object Dictionary** in the fieldbus manual – for Profibus, CAN, EtherCAT – and to the **Data Mapping Table** for Modbus):

Index [hex]		Object	Type	Name	Description	Access
Profibus	Modbus					
200D	0000	ARRAY[200]	INT16	Tab_par [200]	Table of parameters (P00 - P199)	R/W
200E	00C8	ARRAY[100]	INT16	Tab_con [100]	Table of connections (C00 - C99)	R/W
200F	0380	ARRAY[128]	INT16	Tab_int [128]	Table of internal values (D00 - D127)	R
2010	-	ARRAY[32]	INT16	Tab_inp_dig [32]	Current values of standard input logic functions	R
2011	-	ARRAY[32]	INT16	Tab_out_dig [32]	Current values of standard output logic functions	R
2012	0C00	ARRAY[100]	INT16	Tab_osc [100]	Current monitorable size values (osc0 – osc99)	R
2013	-	VAR	UINT16	Input	Logic 8 input status to terminal board	R
2014	-	VAR	UINT16	Input_hw	Logic 3 input status from power	R
2015	-	VAR	UINT16	Output_hw	Logic 4 digital output status	R
2016	0340	VAR	UINT32	Out_dig_appl	Application output function reading via fieldbus	R
2017	0200	VAR	UINT16	Status	Converter variable status	R
2018	0202	VAR	UINT16	Alarms	Converter alarm status	R
2019	0203	VAR	UINT16	Enable_alarms	Converter alarm enabling word	R
201E	012C	ARRAY[100]	INT16	Tab_dati_applicazione [100]	Table of application paramters (E00 - E99)	R/W
201F	0360	VAR	UINT32	Inp_dig_field	Input logic function writing via fieldbus	W
2020	0300	VAR	UINT32	Inp_dig	Input logic function reading via fieldbus	R
2021	0320	VAR	UINT32	Out_dig	Standard logic output reading via fieldbus	R
2022	-	VAR	UINT16	Word_vuota	Unused word	R/W
2023	-	VAR	UINT32	double_vuota	Unused double word	R/W
2025	-	ARRAY[16]	INT16	Tab_codice_allarmi [16]	Subcode table of active alarms	R
2027	-	ARRAY	UINT16	tabProcessData	Process variable mapping	R/W
-	052C	ARRAY[200]	UINT16		Table of parameters format	R
-	084C	ARRAY[100]	UINT16		Table of connections formats	R
-	0C00	ARRAY[100]	UINT16		Table of monitor and analog outputs values	R
-	0D00	ARRAY[100]	UINT16		Table of application parameters formats	R
-	09DC	ARRAY[128]	UINT16		Table of internal values format	R

NOTE:: In case of Profibus, the variables shown in **bold** are mappable in the process area.

In addition to the variables already mapped by default with the AFE core sw, some additional variables have been mapped in order to be used as commands/references through the fieldbus. They are listed in the table below.

Index [hex]	Obj	Type	Name	Description	Acc.	Min	Max	Def	u.m.	Scale
2100	VAR	UINT16	VbusOvdFieldbus	Fieldbus DC Bus voltage override	R/W	0.0	100.0 ^{P107} _{P08}	100.0	%P08- DC_BUS_REF	16384
2101	VAR	INT16	IqRefFiedlbus	Fieldbus active current reference	R/W	-100.0	100.0	0.0	%P53-I_CONV_NOM	16384
2102	VAR	INT16	IdRefFiedlbus	Fieldbus reactive current reference	R/W	-100.0	100.0	0.0	%P53-I_CONV_NOM	16384
2103	VAR	UINT16	MaxIqFieldbus	Fieldbus active current limit	R/W	0.0	200.0	200.0	%P53-I_CONV_NOM	16384
2104	VAR	UINT16	VgridOvdFieldbus	Fieldbus AC voltage override	R/W	0.0	200.0	100.0	%P10- V_GRID_ISL	16384
2105	VAR	UINT16	FreqOvdFieldbus	Fieldbus AC frequency override	R/W	0.0	200.0	100.0	%P63- F_GRID_NOM	16384
2106	VAR	UINT16	VBLimMaxOvdFieldbus	Fieldbus DC Bus max limit override	R/W	0.0	100.0	100.0	%E55-VB_MAX	16384
2107	VAR	UINT16	VBLimMinOvdFieldbus	Fieldbus DC Bus min limit override	R/W	0.0	100.0	100.0	%E56-VB_MIN	16384
2108	VAR	INT16	PgridRefFieldbus	Fieldbus active power reference	R/W	-100.0	100.0	0.0	%D82-S_NOM	16384
2109	VAR	INT16	QgridRefFieldbus	Fieldbus reactive power reference	R/W	-100.0	100.0	0.0	%D82-S_NOM	16384

5 ITALIAN GRID CODE OVERVIEW

The tables below list the functions required by the Italian grid code:

- standard CEI 0-21 for Low Voltage connection;
- standard CEI 0-16 for Medium Voltage Connection;

and indicate the activation method and if they are relevant depending on the application.

Function		CEI 0-21 (LV)				
		by default	Activation method		Applicable	
			on demand from DSO	choice of the plant owner	Static Converter (PV/ESS)	Full Converter (WIND/HYDRO)
Grid connection requirements		✓	-	-	✓	✓ (power ramp excluded)
Q	cosphi(P)	-	✓	-	✓	✓
	Q external command	-	✓	-	✓	✓
	Q(V)	-	✓	-	✓	✓
P	P(V)	-	-	✓	✓	✓
	P(f)	✓	-	-	✓	✓
	P external limit	-	✓	-	✓	✓
VFRT	LVFRT	✓	-	-	✓	-
	OVFRT	-	-	-	-	-

Function		CEI 0-16 (MV)				
		by default	Activation method		Applicable	
			on demand from DSO	choice of the plant owner	Static Converter (PV/ESS)	Full Converter (WIND/HYDRO)
Grid connection requirements		✓	-	-	✓	✓
Q	cosphi(P)	-	✓	-	✓	✓
	Q external command	✓ (Static Conv)	✓ (Full Conv)	-	✓	✓
	Q(V)	-	✓	-	✓	✓
P	P(V)	-	-	✓	✓	✓
	P(f)	✓	-	-	✓	✓
	P external limit	-	✓	-	✓	✓
VFRT	LVFRT	✓	-	-	✓	-
	OVFRT	✓	-	-	-	-

5.1 ACTIVE POWER LIMITATION MANAGEMENT

Some of the functions required by the CEI 0-21 or CEI 0-16 standards will limit the active power injected into the grid. This power reduction is performed automatically by OPDE AFE ENERGY converter that signals the insertion of the active power limit with the logic output **O36 - Active Power Limitation** and indicates in the variable **D84-P_active_limit** and **osc86 - P_active_limit**, the instantaneous value of the power limit, with scale 4096 and u.m [% D82-S_NOM].

The automation system (hydro, wind, ORC or other), which manages the power converted by the generator must appropriately use this power limit in order to limit the power generated from the inverter, in order to ensure a safe operation of the plant and avoid a DC bus over voltage alarm.152

Because the active power limitation of the AFE is executed instantaneously, the automation system must immediately reduce the power generated from the inverter. Usually the automation system takes some seconds to reduce the power, therefore an external braking resistor must be used to dissipate the transient power surplus.

The following figure shows schematically an example of an automation system with hydro turbine where it is highlighted the exchange of signals O36 and osc86 through the communication bus between OPDE AFE ENERGY and the PLC control/automation system.




Figure 30 – Example of hydro power generation system

6 ALARMS

The converter has a set of alarms that stop the converter if there is a fault in order to prevent damage. In case of an alarm event, the converter output phases (U,V,W) are blocked and the DC Bus Voltage is no longer controlled.

If one or more of the alarms occur, they are signalled on the displays, which start to blink and to show a cycle of all the alarms triggered (the 7-segment display shows the alarms that have been set off in hexadecimal).

In case of failure of the converter, or if an alarm is triggered, check the possible causes and act accordingly.

If the causes cannot be traced or if parts are found to be faulty, contact TDE MACNO and provide a detailed description of the problem and its circumstances.

The alarm indication is divide in 16 categories (A0=A15) and for each alarm there's a sub-code to better identify the alarm (AXX.YY)

ALARM			DESCRIPTION	CORRECTIVE ACTION
HEX	DEC			
A.1.0.H	A01.0	EEPROM alarm Read failure	A Check Sum error occurred while the EEPROM was reading the values. Default values loaded automatically.	Try to reread the values with the EEPROM. The reading may have been disturbed in some way. If the problem continues contact TDE as there must a memory malfunction.
A.1.1.H	A01.1	EEPROM alarm Write failure	When data is being written in the EEPROM the required values are always shown afterwards: an alarm triggers if differences are detected.	Try to rewrite the values in the EEPROM. The information may have been disturbed in some way. If the problem continues contact TDE as there must be a memory malfunction.
A2.0 H	A02.0	Alarm for grid fault / sequence of phase L1, L2, L3 not connected	The grid voltage amplitude (D21) read with the synchronization signal is below threshold P50.	If the grid voltage has not been connected to the AFE, this is a normal alarm. Otherwise check the connection on the gride side and the synchronization signals.
A.3.0.H	A03.0	Power fault	The converter output current has reached a level that has set off an alarm; this may be caused by an overcurrent due to leakage in the wires. There may also be a fault on the regulation card or a problem in the synchronization wires.	Check the connection wires on the line side, in particular on the terminals, in order to prevent leakages or short circuits. Check that the connections of the synchronization circuit is correct according to the Installation manual (OPDE_AFE_INSTALLATION).
A.4.0.H	A04.0	Waiting time for grid voltage and frequency control	Only with E93=1. Possible causes: a) input I31-Interface protection ok is at low level; b) the inverter is not connected to the grid; c) the inverter is connected to the grid but D86-Vgrid or D87-Fgrid are out of the acceptance thresholds, d) voltage and frequency have the right value but the waiting time is not ended.	Check status of external Interface Protection (PI) connected to input I31. Check D86-Vgrid_CONN_MANAGE value that should be: E05 < D86 < E04 and D87-Fgrid_CONN_MANAGE value that should be: E07 < D87 < E06 Check if counter D88 and counter D89 are running. Refer to par. 4.16.1
A.4.1.H	A04.1	Anti-Islanding frequency error	Only with E96=1.	Refer to par. 4.22
A.4.2.H	A04.2	Grid Over Frequency during run	Only with E93=2. D87-Fgrid has exceeded the threshold E06 or E11	Check D87-Fgrid_CONN_MANAGE value that should be: D87 < E06 Refer to par. 4.16.2
A.4.3.H	A04.3	Grid Over/Under Voltage during run	Only with E93=2. D86-Vgrid has exceeded the threshold E05 or E04	Check D86-Fgrid_CONN_MANAGE value that should be: E05 < D86 < E04 Refer to par. 4.16.2
A.4.4.H	A04.4	Fieldbus problem		
A.4.5.H	A04.5	Idc overcurrent	Only with E216=1. The Idc current on phase U, V or W has exceed threshold E223 with time filter E237 or threshold E240 with time filter E238.	Verify that the Rgrid tuning test has been executed (E226 should be different from default value)

A.5.0.H	A05.0	Thermal alarm. Reactor temperature too high	Connection C46 manages a range of heat probes. If C46=1 or 2, a PTC/NTC is being used and its Ohm value (D41) has exceeded the safety threshold (P95). If C46 = 3 a digital input has been configured to I23 logical input function and this input is in not active state. If C46=4, a KTY84 is being used: the temperature reading (D26) must be higher than the maximum temperature (P91).	Check the temperature reading in D26 and then check the reactor. With a KTY84, if -273.15 appears the electrical connection towards the reactor heat probe has been interrupted. If the reading is correct and the reactor is overheating, check that the reactor cooling circuit is intact. Check the fan, its power unit, the vents, and the air inlet filters on the cabinet. Replace or clean as necessary. Ensure that the ambient temperature around the reactor is within the limits permitted by its technical characteristics.
A.5.1.H	A05.1	Thermal alarm. Heat sink temperature too high	The heatsink temperature (D25) is higher than the maximum (P118).	Check the temperature read in D25 and then check the heat sink. If -273.15 is displayed, the electrical connection towards the heat sink heat probe has been interrupted. If the reading is correct and the reactor is overheating, check the converter cooling circuit being intact. Check the fan, its power unit, the vents, and the air inlet filters on the cabinet. Replace or clean as necessary. Ensure that the ambient temperature around the converter is within the limits permitted by its technical characteristics. Check parameter P118 is set correctly.
A.5.4.H	A05.4	Thermal alarm. Reactor thermal probe not connected	Thermal probe of the reactor not detected	Check the connection of the probe.
A.5.5.H	A05.5	Thermal alarm. Run with T_heat_sink too high	Run with T_heat_sink > P119	Check the heat sink temperature (D25)
A.7.0.H	A07.0	Grid over-voltage (Vmains)	The grid voltage amplitude (D21) read with the synchronization signal increase over threshold P51.	Grid fault or distribution grid not adequate to the load conditions.
A.8.0.H	A08.0	External alarm. Missing enable logic input from the field (I08)	A digital input has been configured to I02 logical input function and this input is in not at high logic level.	The external safety switch has cut in disabling converter enable. Restore and reset. The connection has been broken. Check and eliminate the fault. Input function has been assigned, but enable has not been given. Authorise or do not assign the function.
A.8.1.H	A08.1	External alarm. Watchdog alarm LogicLab	A LogicLab watchdog alarm on slow cycle appears.	Check if the LogicLab slow task duration is greater than 500 ms and try to reduce this execution time.
A.8.2.H	A08.2	External alarm. Fast task LogicLab too long in execution time	The LogicLab fast task is too long in time	Try to reduce the LogicLab fast task execution time under admitted limit. Please refer to the specific documentation.
A.8.3.H	A08.3	External alarm. Application out of service	There is no valid application running in the converter.	Reload the application using OPDEplorer.
A.A.0.H	A10.0	Minimum power circuit voltage. DC Bus under minimum threshold admitted (DC_MIN, P106)	DC Bus voltage (D24) has dropped below the minimum value (P106).	If the grid voltage has not been connected to the AFE, this is a normal alarm. Otherwise, a grid fault occurred, or the distribution grid is not adequate to the load conditions.
A.B.1.H	A11.1	Power circuit overvoltage. HW detection	DC Bus voltage (D24) has exceeded the HW threshold.	
A.B.2.H	A11.2	Power circuit overvoltage. SW detection	DC Bus voltage (D24) has exceeded the threshold P107	
A.B.3.H	A11.3	Power circuit overvoltage. HW + SW detection	A11.0 and A11.1 appears	

A.C.0.H	A12.0	Internal alarm. C29 different from 1	C29 different from 1	Check and enable connection C29 "Converter software enable"
A.C.0.H	A12.0	Internal alarm. C29 different from 1	C29 different from 1	Check and enable connection C29 "Converter software enable"
A.C.1.H	A12.1	Internal alarm. Run without power soft start	RUN without Power Soft start	Check why the Power Soft start did not charge the bus
A.E.0.H	A14.0	Missing loading of the bus during precharge	The grid voltage amplitude (D21) read with the synchronization signals is within the allowable range, but the DC Bus has not been precharge.	Check the power connections towards the grid.



Figure 32 – Remote keypad for PV application

7.3 DISPLAY – REMOTE KEYPAD USE

For a complete description on how to use the display and the remote keypad refer to the **AFE user manual**.

8 REVISION HISTORY

OPDE Energy Application Revision	Date	Changes introduced in different versions
Rev 1.00	28/03/2017	First release



ECS
TDE MACNO

Via dell'Oreficeria, 41
36100 Vicenza - Italy
Tel +39 0444 343555
Fax +39 0444 343509
www.bdfdigital.com